



BOSCH

Stand

BT 152 | 3 601 K91 610

Table of Content


Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description	Illustration
801	1 619 PB0 670	Head	1
803	1 619 PB0 680	locking assembly	1
806	1 619 PB0 675	Swing Clamp	1
807	1 619 PB0 676	Clamp	1
808	1 619 PB0 677	Bolt	1
809	1 619 PB0 678	Bushing	1
820	1 619 PB0 703	Bracket assembly	1
829	1 619 PB0 698	Protection cover	1
830	1 619 PB0 699	Fastening strap	1

Illustration - Type - E

3 601 K91 610
Issue |
Stand | 16-09-30 Fig./Abb. 1



Modifications reserved
Änderungen vorbehalten
Modifications réservées
Salvo modificaciones