



Parts List for BTE300K Type 1

Item Number	Part Number	Description	Qty Required
1	5140071-59	ARBOR BOLT	1
2	5140034-36	CLAMP	1
4	5140034-34	INNER FLANGE	1
5	5140034-04	SCREW	1
6	5140129-89	GUARD LEVER	1
7	5140034-02	CIRCLIP	1
8	5140114-97	LOWER GUARD	1
9	5140033-99	BUSHING	1
10	5140034-00	TORSION SPRING	1
11	5140071-69	SCREW	3
19	5140033-94	LOCK RING	1
20	5140071-71	HEX SOC HD SCR	1
21	5140071-72	STOPPER	1
22	5140114-98	GEAR CASE ASSY.	1
23	5140033-93	SPRING	1
24	5140033-92	SPINDLE LOCK	1
25	5140033-91	BUTTON	1
26	5140033-71	RUBBER RING	1
27	5140034-18	E-RING	1
28	5140114-99	FAN BAFFLE	1
29	5140071-81	ARMATURE	1
30	5140033-66	WASHER	1
31	5140033-65	SPRING	1
32	5140033-75	SCREW	1
33	5140033-74	SPRING WASHER	2
34	5140033-73	PLAIN WASHER	2
35	5140071-87	FIELD	1

Parts List for BTE300K Type 1

Item Number	Part Number	Description	Qty Required
36	5140115-00	MOTOR HOUSING	1
37	5140115-01	SCREW	3
38	5140033-62	BRUSH	2
39	5140033-63	BRUSH HOLDER	2
40	5140033-61	BRUSH HOLDER PLATE	2
41	5140071-94	SCREW	3
42	5140129-90	REAR COVER	1
43	5140071-96	BOLT	2
44	5140071-97	WASHER	2
45	5140076-48	LOCK ROD	2
46	5140115-02	LEVER	2
47	5140115-03	E-RING	2
57	5140076-52	SPRING PIN	1
58	5140129-91	RIGHT HANDLE	1
59	5140076-40	SLEEVE	1
60	5140034-11	SPONGE	1
61	5140076-45	SWITCH	1
62	5140129-92	LEFT HANDLE	1
63	5140076-47	SCREW	8
64	5140034-14	SCREW	2
65	5140034-13	CORD CLAMP	1
66	5140076-56	CORD SET	1
67	5140034-12	CORD PROTECTOR	1
68	5140076-41	ASSY WIRE	2
69	5140076-50	WING NUT	1
70	5140033-96	SPRING	1
71	5140034-39	WRENCH	1

c

Parts List for BTE300K Type 1

Item Number	Part Number	Description	Qty Required
72	5140076-55	RIP FENCE	1
201	5140071-70	GEAR ASSY.	1
202	5140076-54	SHOE ASSY.	1