


RYOBI TABLE SAW - MODEL NO. BTS10S

FIGURE A



RYOBI TABLE SAW – MODEL NO. BTS10S


The model number will be found on the data plate attached to the back panel of the cabinet. Always mention the model number in all correspondence regarding your **TABLE SAW** or when ordering repair parts.

PARTS LIST FOR FIGURE A

Key No.	Part No.	Description	Qty.	Key No.	Part No.	Description	Qty.
1	410282702	SCREW (3/16-24 x 3/8 in. HEX HD.)	1	25	0101010301	THROAT PLATE INSERT	1
2	412042001	EXTERNAL TOOTH LOCK WASHER	1	26	410192001	SCREW (M4 x 10 mm TRUSS HD.)	2
3	0101140303	POINTER	1	27	0101141303	RUBBER WASHER	2
4	410012703	SCREW (5/16-18 x 5/8 in. HEX HD.)	1	28	411182001	J-TYPE TINNEMAN NUT	2
5	0101140304	POINTER SEAT	1	29	410138701	SCREW (1/4-20 x 7/8 in. PAN HD. NYLOCK)	1
6	0101010907	SPRING	1	30	410102702	SCREW (1/4-20 x 7/8 in. FLAT HD.)	6
7	412012708	FLAT WASHER	1	31	410138702	SCREW (1/4-20 x 29 mm PAN HD.)	1
8	0101010906	SPRING	1	32	9101140000302	SCALE LABEL	1
9	412012702	FLAT WASHER	1	33	0101010303	STRAP	6
10	410012702	SCREW (1/4-20 x 3-1/4 in. HEX HD.)	2	34	A101140807	MITER GAUGE ASSEMBLY	1
11	412012701	WASHER (D1/4 x D16 x t1)	3	35	A101140903	RIP FENCE ASSEMBLY	1
12	411012701	HEX NUT (1/4-20)	3	36	A101141001	BLADE GUARD ASSEMBLY	1
13	0101010903	SPACER	1	37	412042702	LOCK WASHER EXTERNAL	1
14	412042701	FLAT WASHER	3	38	410152716	SCREW (1/4-20 x 1/2 in. SOC. HD.)	2
15	411012702	HEX NUT (5/16-18)	4	39	0101010111	SPREADER SEAT	1
16	410032720	CARRIAGE BOLT (1/4-20 x 2 in.)	1	40	412042702	LOCK WASHER EXTERNAL	1
17	0101010905	SPACER	1	41	412032701	LOCK WASHER INTERNAL	1
18	9181015330202	LABEL (NO HANDS)	1	42	410151709	SOCKET HEAD SCREW (1/4-20 x 57 mm)	1
19	0101210902	BLOCK	1	43	412012030	WASHER	2
20	9121015333301	INSERT WARNING LABEL	1	44	0101210304	FRONT GUARD	1
21	411062701	NUT (1/4-20 CHEESE HD.)	11	45	410012701	SCREW (1/4-20 x 1/2 in. HEX HD.)	1
22	410162003	SCREW (M6 x 18 mm CHEESE HD.)	1	46	414011002	SPRING PIN	1
23	A101214301	BRACKET ASSEMBLY	1	47	9181015330203	BLADE GUARD LABEL	1
24	0101140102	SAW TABLE	1				

RYOBI TABLE SAW - MODEL NUMBER BTS10S

FIGURE B



RYOBI TABLE SAW – MODEL NUMBER BTS10S

The model number will be found on a plate attached to the back panel of the cabinet. Always mention the model number in all correspondence regarding your **TABLE SAW** or when ordering repair parts.

PARTS LIST FOR FIGURE B

KEY NO.	PART NUMBER	DESCRIPTION	QTY.	KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	410182001	SCREW (M4 x 7 mm FLAT HD. TAPPING)	8	25	0152010204	HAND WHEEL KNOB	1
2	0101010201	GEAR PLATE	1	26	0101140203	SPECIAL HAND WHEEL SCREW	1
3	0101040305	REINFORCEMENT PLATE.....	1	27	0101140206	HAND WHEEL INSERT.....	1
4	412042002	EXTERNAL TOOTH LOCK WASHER	1	28	414011003	SPRING PIN	1
5	410132005	PAN HEAD SCREW	1	29	0101140801	ELEVATING SHAFT	1
6	0101040203	CORD CLAMP.....	1	30	0101140213	SWITCH KEY.....	1
7	410192002	SCREW (M4 x 16 mm PAN HD. TAPPING)	7	31	080015001640	SWITCH	1
8	0152011814	GROMMET	1	32	A101140109	MOTOR ASSEMBLY W/GUARD	1
9	0101140701	POWER CORD	1	33	0101015002	BRUSH ASSEMBLY	2
10	411072702	LOCK NUT (1/4-20).....	1	34	***	10 in. BLADE (422010025)	1
11	0101090302	CORD CLAMP.....	1	35	0101010302	OUTER BLADE WASHER.....	1
12	0101090201	SWITCH BOX	1	36	0101010920	ARBOR NUT (5/8-18)	1
13	410162004	SCREW (M6 x 25 mm CHEESE HD.)	4	37	0101010312	15/16 in. ARBOR WRENCH	1
14	0111140208	RUBBER FOOT	4	38	0101010313	WRENCH.....	1
15	9101145330203	WARNING LABEL.....	1	39	0201010904	HEX KEY (M5 x 57 mm).....	1
16	9101145330204	DATA LABEL.....	1	40	0101210208	GUARD (BAFFLE PLATE)	1
17	0101140220-42	CABINET	1	41	0101140218	BEVEL LOCK LEVER.....	1
18	9101145330101	FRONT PANEL LABEL	1	42	0101140904	SPRING.....	1
19	412080001	NYLON WASHER.....	1	43	A101145201	BEVEL LOCK LEVER ASSEMBLY (INC. PAGE 2 KEY NOS. 11, 12, 13, AND 16; PAGE 4 KEY NOS. 19-22 AND 41-42)	1
20	412012701	FLAT WASHER (D1/4 x D16 x t1)	2		983000355	OPERATOR'S MANUAL	1
21	411012701	HEX NUT (1/4-20).....	1		12-05-07		
22	0101140221	LOCK NUT.....	1		(REV:04)		
23	0101140205	HAND WHEEL	1				
24	412011712	FLAT WASHER	1				

*** Standard Hardware Item — May Be Purchased Locally