



Parts List for CD121K-B3 Type 2

Item Number	Part Number	Description	Qty Required
1	5140056-39	SCREW	7
2	5140056-40	HOUSING ASSY.	1
3	5140056-41	SWITCH ASSY.	1
4	5140056-42	12V BATTERY PACK	1
5	5140024-83	RING	1
6	5140062-09	SPRING	1
7	5140024-85	RING	1
8	5140062-10	COLLAR,CLUTCH	1
9	5140024-87	SPRING	1
10	5140024-88	HOLDER	1
11	5140024-89	SCREW	2
12	5140024-90	CHUCK	1
13	5140024-91	CHUCK SCREW	1
14	5140024-92	BALL GROUP	16
15	5140024-93	RING	1
16	5140024-94	RING	2
17	5140024-95	BALL GROUP	15
18	5140024-96	GOVERNOR BOX	1
19	5140024-97	SHAFT COAT	1
20	5140024-98	SHAFT	1
21	5140024-99	GEAR RING	1
22	5140025-73	GEAR	3
23	5140025-74	BRACKET	1
24	5140025-75	PLANET GEAR	3
25	5140025-76	WASHER	1
26	5140025-77	SCREW	2
27	5140025-78	FLANGE	1

Parts List for CD121K-B3 Type 2

Item Number	Part Number	Description	Qty Required
28	5140025-79	SCREW	1
29	5140025-80	MOTOR	1
31	5140025-82	SCREWDRIVER BIT	2
32	5140025-83	BIT CLIP	2
33	5140056-44	LEVER,SHIFT	1
34	5140056-45	BATTERY BASE SUPPORT	1
35	5140062-15	CHARGER	1
36	5140056-49	NAME PLATE	1
37	5140056-46	BRAND LABEL	1
38	5140058-78	WRIST STRAP	1
39	5140058-80	SELF TAPPING SCREW	3