



Parts List for CD182SB-2 Type 1

Item Number	Part Number	Description	Qty Required
1	90505737	CLAMSHELL SET	1
2	5146273-00	ACTUATOR FWR/REV	1
3	148354-03	BIT CLIP	1
4	90510108	MOTOR & PINION	1
5	90504625	TRANSMISSION ASSY.	1
6	419233-10	KEYLESS CHUCK	1
7	149518-01	SCREW	1
8	90510109	SWITCH, V.S.R.	1
9	90504622	NAMEPLATE	1
10	5146650-00	INSERT	1
11	311993-00	SCREW	5
12	498511-00	SCREW	1
13	5100035-01	SPRING	2
14	419581-01	BIT	1
15	5146272-02	COVER	1
16	90527167	SHIFTER	1
18	5100918-00	ROLL PIN	1
862	90528790	STORAGE BAG	1
866	HPB18	BATTERY	2
867	5102026-00	BATTERY CAP	1
871	5103069-12	CHARGER	1