



Parts List for CD231K-2 Type 1

Item Number	Part Number	Description	Qty Required
1	497014-01	CLAMSHELL SET	1
2	311978-01	F/R ACTUATOR	1
3	148354-03	BIT CLIP	1
4	607918-41	SCREWDRIVER BIT	1
5	000000-00	No Longer Available	1
6	000000-00	No Longer Available	1
7	151222-00	MOTOR	1
8	330013-03	SCREW	4
9	498796-00	KEYLESS CHUCK	1
10	149518-01	SCREW	1
11	311975-01	TOP,INSERT	1
12	497018-09	NP:CD231 T1	1
13	000000-00	No Longer Available	1
14	046376-00	PIN	1
15	330019-00	SCREW	2
16	PS120	9.6V BATTERY PACK	1
17	418352-00	PS150 9.6V CHARGER	1
861	000000-00	No Longer Available	1