



Parts List for CDC120ASB Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|-----------------|--------------|
| 1 | 90503056-01 | CLAMSHELL SET | 1 |
| 2 | 90503047 | F/R ACTUATOR | 1 |
| 3 | 148354-03 | BIT CLIP | 1 |
| 5 | 90503087 | MOTOR & GEARBOX | 1 |
| 6 | 419233-10 | KEYLESS CHUCK | 1 |
| 7 | 149518-01 | SCREW | 1 |
| 8 | 90503081 | VSR SWITCH | 1 |
| 9 | 90501712 | NAMEPLATE | 1 |
| 10 | 90501711 | BRAND LABEL | 1 |
| 11 | 5106167-00 | SCREW | 2 |
| 12 | 311993-00 | SCREW | 4 |
| 13 | 5146421-00 | SCREW | 2 |
| 14 | 90503048 | REAR COVER | 1 |
| 15 | 419581-01 | BIT | 1 |
| 16 | 5145496-00 | SPRING | 2 |
| 861 | 90539916 | STORAGE BAG | 1 |
| 866 | HPB12 | BATTERY PACK | 1 |
| 867 | 5102026-00 | BATTERY CAP | 1 |
| 871 | 5102767-08 | CHARGER | 1 |