

Parts List for CM2060C Type 1

Item Number	Part Number	Description	Qty Required
2	5140188-01	COVER	1
3	5140188-02	GASKET	1
4	5140188-03	LOWER COVER	1
5	5140192-20	SELF TAPPING SCREW	1
6	5140192-21	SELF TAPPING SCREW	1
7	5140171-27	HANDLE	4
8	5140149-65	SPRING PIN	4
9	5140192-22	FIXED SEAT	2
10	5140149-67	CLAMP LEVER	2
11	5140192-23	PAD	4
12	5140192-24	KNOB	2
13	5140149-71	HEX NUT	2
14	5140192-25	LOWER HANDLE	1
15	5140188-16	WIRE PIE	1
16	5140192-26	CLAMP,SUPPORT	2
17	5140161-19	SHAFT	2
18	5140192-27	ADJUSTING GEAR	2
19	5140179-38	FRAME,GRASS BAG	1
20	5140192-28	GRASS BAG	1
22	5140192-32	SELF TAPPING SCREW	19
23	5140188-07	WHEEL PLATE	6
24	5140192-33	SELF TAPPING SCREW	2
25	5140161-29	FIXED PLATE	2
26	5140161-30	SOFT PLATE	1
27	5140192-34	SCREW	2
29	5140192-45	BLOCK	1
30	5140192-46	SIDE DSCHG.ATTACH	1

Parts List for CM2060C Type 1

Item Number	Part Number	Description	Qty Required
32	5140161-49	BLADE	1
33	5140150-06	BLADE CLAMP	1
34	5140150-07	BLADE BOLT	1
36	5140161-69	SELF LOCK NUT	2
37	5140161-77	SCREW	1
38	5140192-51	HEIGHT ADJ. HANDLE	1
39	5140150-31	SCREW	3
40	5140192-52	MOTOR	1
41	5140192-53	TOP COVER	1
43	5140192-75	CABLE CLAMP	1
44	5140173-97	SCREW	10
45	5140192-76	CABLE	1
46	5140149-55	CABLE CLAMP	1
81	5140192-35	SELF TAPPING SCREW	3
82	5140161-39	GUIDE PLATE	1
83	5140192-36	SELF TAPPING SCREW	5
84	5140161-40	AXLE	1
85	5140161-41	LOCK WASHER	1
86	5140188-08	RUBBER CAP	1
87	5140161-43	TORSION SPRING	1
88	5140161-44	SIDE COVER	1
89	5140192-37	FIXED SEAT	1
200	5140192-12	SWITCH BOX ASSY	1
201	5140192-13	SLEEVE	1
202	5140192-14	UPPER HANDLE ASSY.	1
203	5140160-99	BUTTON	1
204	5140149-41	SPRING	1

Parts List for CM2060C Type 1

Item Number	Part Number	Description	Qty Required
205	5140161-00	COVER	1
206	5140149-45	SWITCH AND CABLE	1
207	5140187-98	TRIGGER BUTTON	1
208	5140192-15	SWITCH	1
209	5140149-42	BUTTON	1
210	5140192-16	SELF TAPPING SCREW	1
211	5140149-51	SCREW	1
212	5140149-50	HOOK PLATE	1
213	5140149-54	HEX NUT	1
214	5140149-52	TORSION SPRING	1
215	5140161-03	GUIDE	1
216	5140149-57	CONNECTOR-WIRE	1
217	5140192-17	CABLE	1
218	5140192-18	FLANGE SCREW	4
219	5140149-48	CLAMP	1
220	5140149-60	BUSHING	2
221	5140192-19	HEAT SHRINK SLEEVE	1
222	5140161-04	LOWER COVER	1
223	5140149-55	CABLE CLAMP	1
224	5140173-97	SCREW	8
225	5140161-05	KEY BOX ASSY.	1
226	5140188-00	KEY STRAP	1
301	5140188-10	FAN	1
302	5140192-47	FLANGE SCREW	2
303	5140161-48	PLATE	1
311	5140192-29	WHEEL COVER	2
312	5140161-22	RETAINING RING	2

Parts List for CM2060C Type 1

Item Number	Part Number	Description	Qty Required
313	5140192-30	REAR WHEEL	2
314	5140192-31	GASKET	2
315	5140161-25	REAR AXLE	1
351	5140192-48	WHEEL COVER	2
352	5140161-22	RETAINING RING	2
353	5140192-49	WHEEL	2
354	5140192-50	WAVY WASHER	2
355	5140161-52	FRONT AXLE	1
411	5140161-88	TORSION SPRING	1
412	5140161-65	SOFT BOARD	1
413	5140192-54	HEIGHT ADJUST COVER	1
414	5140192-55	SELF TAPPING SCREW	2
415	5140192-56	SELF TAPPING SCREW	4
416	5140192-57	TOP COVER HANDLE	1
417	5140192-58	REAR COVER	1
418	5140161-86	CIRCLIP	2
419	5140192-59	REAR COVER SHAFT	1
421	5140150-45	ANTI LOCK SPRING	4
423	5140173-97	SCREW	12
424	5140192-68	SOCKET	1
425	5140192-69	SOCKET	1
426	5140192-70	COVER	1
427	5140192-71	COVER	1
428	5140192-72	CLAMP	1
429	5140192-73	BATTERY HOLDER	1
501	5140192-60	ELECTRONIC BOARD	1
502	5140192-61	FLANGE SCREW	2

Parts List for CM2060C Type 1

Item Number	Part Number	Description	Qty Required
503	5140192-62	CLAMP	2
504	5140192-63	PLATE	1
505	5140192-64	FLANGE SCREW	2
506	5140192-65	GUIDE	2
507	5140192-66	PANEL	1
508	5140192-67	SELECT SWITCH	1
510	5140192-74	SELF TAPPING SCREW	4
810	5140161-34	WASHER	2
811	5140192-38	SELF TAPPING SCREW	3
812	5140161-90	PLATE	1
813	5140192-39	SELF TAPPING SCREW	4
814	5140192-40	HOUSING	1
815	5140192-41	FIXED GEAR	1
816	5140192-42	SELF TAPPING SCREW	4
817	5140149-71	HEX NUT	2
818	5140192-43	FIXED GEAR	1
819	5140192-44	WASHER	1
820	5140161-75	TENSION SPRING	1
821	5140161-74	CONNECTING ROD	1
822	5140150-30	CLAMP HANDLE	2
823	5140161-73	COTTER PIN	1
824	5140161-72	TORSION SPRING	1
825	5140161-71	ROD	1
826	5140161-69	SELF LOCK NUT	2
827	5140161-70	SUPPORT PLATE	1
828	5140161-68	FRONT CONNECTING ROD	1
866	LBX2560	BATTERY	1

Parts List for CM2060C Type 1

Item Number	Part Number	Description	Qty Required
866	LBX1560	BATTERY	1
871	90642267	CHARGER	1
871	BDCAC60B	CHARGER	1