

ELECTRIC TOOL PARTS LIST

■ CORDLESS RECIPROCATING SAW

2021 • 05 • 27

Model CR 18DA

(E1)



