


ELECTRIC TOOL PARTS LIST

■ CORDLESS RECIPROCATING SAW

2022 • 06 • 30

Model CR 18DB

(E1)



STANDARD ACCESSORIES

CR18DB

[illegible]

OPTIONAL ACCESSORIES

[illegible]