



Parts List for CS1020-B2 Type 1

Item Number	Part Number	Description	Qty Required
1	5140051-61	RIGHT HANDLE	1
2	5140050-58	SCREW	3
3	5140049-37	LABEL	1
4	5140050-60	CORD CLAMP	1
5	5140051-62	CORD SET	1
6	5140050-62	WRENCH	1
7	5140050-63	STRAIN RELIEVER	1
8	5140051-63	SWITCH	1
9	5140051-64	LEFT HANDLE	1
10	5140050-66	SCREW	9
11	5140061-06	NAME PLATE	1
12	5140049-46	HOUSING	1
13	5140050-69	BRUSH HOLDER	2
14	5140051-65	BRUSH	2
15	5140050-71	BRUSH CAP	2
16	5140051-66	STATOR	1
17	5140049-51	RING	1
18	5140050-74	SCREW	2
19	5140050-75	SLEEVE BEARING	1
20	5140050-76	BEARING	1
21	5140051-67	ARMATURE (230V)	1
22	5140050-78	BEARING	1
23	5140049-57	LABEL	1
24	5140050-80	UPPER GUARD	1
25	5140050-81	SCREW	1
26	5140050-82	OUTER FLANGE	1
27	5140049-61	SAW BLADE	1

Parts List for CS1020-B2 Type 1

Item Number	Part Number	Description	Qty Required
28	5140049-62	INNER FLANGE	1
29	5140051-02	SCREW	1
30	5140050-86	RING	1
31	5140050-87	KNOB	1
32	5140050-88	LOWER GUARD	1
33	5140050-89	TORSION SPRING	1
34	5140050-90	RING	1
35	5140049-69	SCREW	3
36	5140049-70	GEAR CASE COVER	1
36	5140050-92	COVER	1
36	5140049-72	BEARING	1
36	5140050-94	RING	1
36	5140050-95	OUTPUT SPINDLE	1
36	5140049-75	WOODRUFF KEY	1
36	5140050-97	GEAR	1
42	5140050-98	RING	1
43	5140050-99	NEEDLE BEARING	1
44	5140051-00	SCREW	1
45	5140051-01	GEAR BOX	1
46	5140049-81	SPRING WASHER	3
47	5140049-82	SCREW	3
48	5140051-03	FLAT WASHER	2
49	5140051-04	SPECIAL NUT	1
50	5140051-05	GUARD LEVER	1
51	5140051-06	RETAINING RING	1
52	5140051-07	ROLL PIN	1
53	5140051-08	SPACER	1

Parts List for CS1020-B2 Type 1

Item Number	Part Number	Description	Qty Required
54	5140049-89	SCREW	1
55	5140051-10	WRENCH	1
56	5140049-91	SHOE	1
56	5140049-92	DEPTH ADJ ASSY	1
56	5140049-93	PLATE	1
56	5140049-95	QUADRANT	1
56	5140049-96	RIVET	2
56	5140049-97	INDICATOR	1
56	5140050-06	SCREW	1
59	5140049-98	SCREW	1
60	5140051-17	SPRING WASHER	4
61	5140050-00	FLAT WASHER	1
62	5140051-13	SPRING	1
63	5140051-14	SCREW	1
64	5140051-15	NUT	1
65	5140051-16	SCREW	1
66	5140050-05	NUT	1
68	5140050-07	TOOTH WASHER	3
69	5140051-68	LOCK BUTTON	1
70	5140051-69	SPRING	1