



## Parts List for CS300 Type 1

Item Number	Part Number	Description	Qty Required
1	000000-00	No Longer Available	1
2	144795-00	FIELD	1
4	145377-09	BRUSH & HOLDER	2
5	380775-00	SWITCH,TRIGGER	1
6	000000-00	No Longer Available	1
7	330003-09	BEARING,BALL	1
8	000000-00	No Longer Available	1
9	000000-00	No Longer Available	1
11	000000-00	No Longer Available	1
12	000000-00	No Longer Available	1
13	145301-00	BAFFLE,FAN	1
14	000000-00	No Longer Available	1
15	000000-00	No Longer Available	1
16	000000-00	No Longer Available	1
17	145392-00	COVER,GEAR CASE	1
18	145365-00	BEARING,SLEEVE	1
19	000000-00	No Longer Available	1
20	000000-00	No Longer Available	1
21	145344-00	SCREW,SPECIAL	1
22	000000-00	No Longer Available	1
23	145441-00	WASHER,INR CLMP	1
24	000000-00	No Longer Available	2
26	400677-00	RING,RETAINING	1
27	145312-00	PLUG,RUBBER	1
28	000000-00	No Longer Available	1
29	000000-00	No Longer Available	1
30	330019-14	SCREW	7

## Parts List for CS300 Type 1

Item Number	Part Number	Description	Qty Required
31	000000-00	No Longer Available	2
32	330045-19	SCREW	4
33	098128-97	BOLT	1
34	395889-00	KNOB	2
35	330016-02	WASHER,PLAIN	2
36	098128-15	CARRIAGE BOLT	1
37	000000-00	No Longer Available	1
38	000000-00	No Longer Available	1
39	330045-23	SCREW,TAPTITE	2
40	145375-02	BUMPER	1
41	000000-00	No Longer Available	1
42	000000-00	No Longer Available	1
43	145332-00	TERMINAL	2
44	000000-00	No Longer Available	1
45	000000-00	No Longer Available	1
47	098003-11	SCREW	1
49	330045-27	SCREW	1
50	000000-00	No Longer Available	2
51	330045-06	SCREW	3
52	150466-00	SPRING	1
53	145351-00	WIPER	1
54	145350-00	BUTTON,LOCK	1
55	145349-00	LEVER,LOCK	1
56	000000-00	No Longer Available	1
58	151046-00	WASHER,PLAIN	1
62	000000-00	No Longer Available	1
63	000000-00	No Longer Available	1

## Parts List for CS300 Type 1

Item Number	Part Number	Description	Qty Required
100	132144-00	RIP FENCE	1
103	70910-00	WRENCH	1
800	790206-00	GREASE, 6 OZ.	1
856	000000-00	No Longer Available	1