



## Parts List for D28112-B2 Type 2

Item Number	Part Number	Description	Qty Required
1	188350-03	ARMATURE (230V)	1
2	650994-04	FIELD CASE	1
3	623586-02SV	GEAR CASE ASSY.	1
4	330065-31	SCREW	8
5	648743-00	ARM	2
6	623592-00	FELT SEAL	4
8	636128-03	BRUSH	1
9	623589-00	BRUSH SPRING	2
10	623591-00	CAP	2
11	593685-00	SCREW	2
12	188353-00	HANDLE ASSEMBLY	1
13	641889-00SV	SWITCH	1
14	N055787	SEPARATOR	1
15	628396-00	SPRING	1
16	636963-00	CORD CLAMP	1
17	330019-03	SCREW	1
18	330005-01	PROTECTOR,CORD	1
19	622613-02	KNURLED NUT	1
20	633257-00SV	BACKING FLANGE	1
21	650042-00	GUARD	1
24	330122-46	CORD & PLUG	1
25	637616-00	BAFFLE	1
26	623593-00	TERMINAL	2
27	635892-00	ID LABEL	1
28	659592-05	NAME PLATE	1
70	604484-00	NUT	1
71	623564-00	PINION	1

## Parts List for D28112-B2 Type 2

Item Number	Part Number	Description	Qty Required
72	605040-67	BEARING	1
73	623617-00	FELT SEAL	1
74	623580-00	BRG. RETAINER	1
75	623613-00	SLINGER	1
76	605040-02	BALL BEARING	1
77	641823-00	BEARING CUP	1
78	188344-01	FIELD (230V)	1
79	650997-00	FAN BAFFLE	1
80	330065-25	SCREW	4
81	623618-00	GASKET	1
82	611492-00	SLEEVE,RUBBER	1
83	623562-00	GEAR CASE COVER	1
84	385676-01	SCREW	4
87	N079326	WRENCH	1
88	614796-00	SIDE HANDLE	1
89	623610-00	LINK	1
90	644326-00	BAR	1
91	623608-00	SWITCH BUTTON	1
92	633045-00	O-RING	1
93	633043-00	O-RING	1
836	233804-36	TORX DRIVER	1