



Parts List for DCD939KX Type 2

Item Number	Part Number	Description	Qty Required
1	N016702	CLAMSHELL SET	1
3	148354-03	BIT CLIP	1
4	607918-41	SCREWDRIVER BIT	1
5	N131169	NAME PLATE	1
6	398649-00	FWD/REV BUTTON	1
7	152274-19SV	SWITCH- V.S.R.	1
8	398646-00	MOTOR ADAPTOR	1
9	396505-21SV	MOTOR & PINION	1
10	682211-00	SCREW,TORX	9
11	397892-05SV	TRANSMISSION	1
12	608060-00	DETENT SHIFTER	1
13	586200-10	KEYLESS CHUCK	1
14	395657-00	ID LABEL	1
15	N016837SV	GEARCASE ASSY	1
16	330019-49	SCREW,PLASTIC	4
17	605256-01	SCREW	1
18	399059-00	CAM RETURN SPRING	1
20	603785-00	LEAD WIRE	1
21	603786-00	LEAD WIRE	1
22	603754-01	BRUSH BOX	2
23	939794-00	HANDLE ASSY.	1
24	609133-00	CAP	1
25	604643-00	COLLAR	1
26	395460-00	DETENT SPRING	1
28	611904-00SV	SPINDLE ASSY.	1
861	660141-00	KITBOX	1
866	DC9091	BATTERY PACK	2

Parts List for DCD939KX Type 2

Item Number	Part Number	Description	Qty Required
867	645221-00	BATTERY CAP	2
871	388683-12	1 HOUR CHARGER	1