



Parts List for DCF889L2 Type 1

Item Number	Part Number	Description	Qty Required
1	N209035	HOUSING ASSEMBLY	1
3	330019-24	SCREW	9
4	611202-00SV	MAGNET RING	1
5	N165339	ELEC CONTROL ASSY	1
6	N124832	FWD/REV BUTTON	1
7	N102647	SPRING	1
8	N091479	MOUNT- SPRING	1
9	610023-00	IMPACTOR	1
10	615803-00SV	BARREL	1
11	615801-00SV	ANVIL ASSY.	1
12	610542-00	O-RING	1
13	610539-00	THRUST WASHER	1
14	648605-00	RING GEAR	1
15	610545-00	PLANET GEAR	3
16	611316-00	ROLLER PIN	3
17	611488-00	WASHER	1
19	330019-06	SCREW	4
21	610544-00	CARRIER	1
22	005190-00	BALL	2
23	613461-00	SPRING	1
24	613724-00	THRUST WASHER	2
25	610541-00	THRUST BEARING	1
26	143891-00	PIN	1
26	N020802	DETENT PIN	1
27	099205-07	ROLL PIN	1
28	038769-00	SPRING	1
29	N360879	ARMATURE ASSEMBLY	1

Parts List for DCF889L2 Type 1

Item Number	Part Number	Description	Qty Required
30	391032-00	BEARING & BOOT	1
31	330003-63	BALL BEARING	1
32	330003-12	BEARING,BALL	1
33	N148194	SCREW M3 X 21 T10	1
34	330019-25	SCREW,THD.FORM	2
35	610126-00	BRUSH BOX	2
36	610550-00	FAN BAFFLE	1
37	611205-00	GEARCASE	1
38	N171820	BEARING SUPPORT	1
800	286436-00	GREASE, 500GRAMS	1
800	N017298	GREASE	1
862	N037466	TOOL BAG	1
866	DCB200	BATTERY PACK	2
871	DCB101	CHARGER	1