



Parts List for DCS331B Type 11

Item Number	Part Number	Description	Qty Required
1	586202-01SV	MOTOR ASSY.	1
2	493511-00	BRUSH PAIR KIT	1
4	000000-00	No Longer Available	1
5	496428-00	BAFFLE	1
6	156179-01	SCREW,TAPTITE	3
7	330045-15	SCREW	4
8	N060864	LOCK-OFF BUTTON	1
10	490989-00	PINION	1
11	N091479	MOUNT- SPRING	1
12	N119679	SPRING	1
15	330019-03	SCREW,PLASTITE	9
16	N121960	HOUSING	1
17	581269-00	GUARD	1
21	581577-00	CASTING	1
22	584627-00	PIN	1
23	581418-00	SPRING	1
24	589055-00	ACTUATOR	1
25	590334-02	GEARCASE	1
26	581244-00	GASKET	1
27	330045-09	SCREW	2
30	330045-06	SCREW	2
31	582837-00	BOLT	1
32	N072135SV	BLADE CLAMP	1
33	582262-00	SEAL	1
34	582263-00	FELT SEAL	1
35	586646-00	SPRING,COMP.	1
36	582259-00	BEARING	1

Parts List for DCS331B Type 11

Item Number	Part Number	Description	Qty Required
37	581274-00	RECIP. SHAFT	1
38	582260-00	BEARING CARRIER	1
39	324006-00	SCREW	8
40	490329-00	BEARING	1
46	582261-00	CLAMP	1
47	582257-00	DRIVE ROLLER	1
48	571181-00	CLIP	1
49	582829-00	WASHER	2
50	N466547	SCREW	2
51	330004-02	BEARING,NEEDLE	2
52	N607672	CRANK KIT	1
53	N034837	COUNTERWEIGHT	1
55	N607665	GEAR ASSEMBLY	1
56	581247-00	ACTUATOR	1
58	585113-00SV	GEARCASE ASSY	1
65	581255-05	LEVER	1
66	326467-00	DETENT	2
67	582830-00	BODY	1
68	582831-00	BAFFLE	1
70	589056-00	BRACKET	1
72	330041-29	PIN	1
73	584450-00	NOZZLE	1
74	330041-49	PIN	1
76	581257-01	LEVER	1
77	000000-00	No Longer Available	2
78	N089310	SPRING CLIP	1
85	581263-00	SHOE	1

Parts List for DCS331B Type 11

Item Number	Part Number	Description	Qty Required
86	495746-00	CLAMP LEVER	1
88	584686-00	PLUNGER	1
89	496996-00	CLAMP PLATE	1
90	582826-00	BOLT	1
91	582828-00	WASHER	1
92	582827-00	BOLT	1
94	581264-00	SOLE PLATE	1
95	389235-00	SCREW	4
96	581268-00	SOLE PLATE	1
100	402140-00	DEVICE,ANTI.SPL	1
800	870889-03	GREASE	1
816	N137255	BRAND LABEL	1
821	N416544	RATING LABEL	1
856	N515525	JIG SAW BLADE	1
856	N536023	BLADE PACK	1
856	581239-01	SCREEN	1
856	1004501-00	RIP FENCE	1
861	N179861	KIT BOX	1
866	DCB200	BATTERY PACK	1
871	DCB115	CHARGER	1