



Parts List for DW059K2-AR Type 1

Item Number	Part Number	Description	Qty Required
1	652243-00	CLAMSHELL SET	1
1	610534-00	CLAMSHELL SET	1
2	395047-00	ID LABEL	1
3	330019-04	SCREW,PLASTITE	8
4	611202-00SV	MAGNET RING	1
5	610552-00SV	SWITCH ASSY.	1
6	630518-00	TERMINAL BOARD	1
7	616168-00	LEAD WIRE ASSY	1
8	616169-00	LEAD WIRE ASSY	1
9	610023-00	IMPACTOR	1
10	615803-00SV	BARREL	1
11	615801-00SV	ANVIL ASSY.	1
12	610542-00	O-RING	1
13	610539-00	THRUST WASHER	1
14	648605-00	RING GEAR	1
15	610545-00	PLANET GEAR	3
16	611316-00	ROLLER PIN	3
17	611488-00	WASHER	1
19	330019-06	SCREW	4
20	642509-00	NAMEPLATE	1
21	610544-00	CARRIER	1
22	005190-00	BALL	2
23	613461-00	SPRING	1
24	613724-00	THRUST WASHER	2
25	610541-00	THRUST BEARING	1
26	N020802	DETENT PIN	1
27	099205-07	ROLL PIN	1

Parts List for DW059K2-AR Type 1

Item Number	Part Number	Description	Qty Required
28	038769-00	SPRING	1
29	611200-02SV	ARMATURE ASSY.	1
30	631563-00	BOOT	1
31	330003-63	BALL BEARING	1
32	330003-12	BEARING,BALL	1
33	330019-49	SCREW,PLASTIC	4
34	330019-25	SCREW,THD.FORM	2
35	610126-00	BRUSH BOX	2
36	610550-00	FAN BAFFLE	1
37	611205-00	GEARCASE	1
38	N171820	BEARING SUPPORT	1
800	286436-00	GREASE	1
800	284778-00	GREASE,MOLYKOTE	1
861	N142716	KITBOX	1
866	DC9096	BATTERY PACK	2
867	645221-00	BATTERY CAP	2
871	DW9116-AR	CHARGER	1