



Parts List for DW160V Type 1

Item Number	Part Number	Description	Qty Required
1	619347-00	ARMATURE	1
2	619233-00	FIELD	1
3	445861-26	BRUSH	2
4	445860-00	SPRING,BRUSH	2
5	449899-05	RING,BRUSH	1
7	629457-00	VS SWITCH	1
8	330072-98	CORD/8FT/18-2SJ	1
9	330003-04	BEARING,BALL	2
11	449829-00	NUT, FIELD	2
13	055206-00	SCREW	1
14	133042-00	SCREW	2
15	330019-05	SCREW,PLASTITE	8
16	062812-00	SCREW	3
17	389820-00	SCREW	2
19	449192-00	TERMINAL	2
25	330003-09	BEARING,BALL	1
27	30611-00	PLUG	2
28	95114-00	RUBBER PLUG	1
29	445402-00	PAD, RUBBER	1
30	629045-00	HOUSING & COVER	1
31	449857-00	CASE, GEAR	1
32	449033-01	CASE, GEAR	1
33	131557-00	BEARING,SLEEVE	1
34	448591-00	COVER,GEAR CASE	1
35	445175-00	BEARING, SLEEVE	1
37	429663-00	CHUCK & KEY	1
38	330034-02	CHUCK KEY	1

Parts List for DW160V Type 1

Item Number	Part Number	Description	Qty Required
39	445414-01SV	GEAR & SPINDLE	1
40	445397-03SV	GEAR & PINION	1
42	445217-01	RUBBER CUP	1
43	448595-04	PADDLE	1
45	330005-01	PROTECTOR,CORD	1
47	631466-00	NAMEPLATE	1
48	395047-00	ID LABEL	1
53	065288-02	HOLDER	1
55	448373-00	WASHER,SPRING	1
56	447765-00	WASHER, FLAT	1
62	629458-00	REVERSING SWITCH	1
800	761995-01	GREASE, 6 OZ.	1
800	283484-01	GREASE,32 OZ.	1