



## Parts List for DW317K-B2 Type 2

Item Number	Part Number	Description	Qty Required
1	627380-00	BEARING CARRIER	1
2	098022-26	SCREW	2
3	330045-08	SCREW	2
4	949701-13	SCREW	1
5	330045-45	SCREW	2
6	330019-14	SCREW	3
7	330019-13	SCREW,PLASTITE	5
8	330019-27	SCREW,TORX	2
9	098198-05	WASHER	1
10	586646-00	SPRING,COMP.	1
11	449977-00	QUADRANT	1
12	133825-00	RING	1
13	626990-00	FELT OILER	1
14	098185-20	PIN	1
15	330015-07	NUT,HEX	1
16	582263-00	FELT SEAL	1
17	582259-00	BEARING	1
18	080164-00	SCREW	1
19	133761-00	WEIGHT	1
20	620203-01	ROLLER	1
21	623199-00	BLADE CLAMP ASY	1
22	623489-00	GASKET	1
23	133820-00	PIN	1
24	133750-00	CLAMP	1
25	133751-00	SHIELD	1
26	370167-00	SCREW	2
27	133755-00	SEAL	1

## Parts List for DW317K-B2 Type 2

Item Number	Part Number	Description	Qty Required
28	623188-00	RECIP. SHAFT	1
29	623190-00	BELL CRANK	1
30	133799-00	FORK	1
31	133770-00	SHOE	1
32	133827-02SV	GEAR & BEARING	1
33	625341-00	GEAR CASE ASSY.	1
34	623193-00	COVER	1
35	623201-00SV	CRANK PLATE	1
36	N074210	HANDLE SET	1
38	N055693	SWITCH	1
39	147581-00	LEAD WIRE	1
40	N080248	CORD	1
41	330005-01	PROTECTOR,CORD	1
42	618805-01SV	ARMATURE	1
44	625260-00	WIRE GUARD	1
45	N075584	NAMEPLATE	1
46	395047-00	ID LABEL	1
47	609729-00	LABEL, INSTR.	1
48	445876-00	BAFFLE, FAN	1
49	445217-01	RUBBER CUP	1
50	445861-30	BRUSH & LEAD	2
51	582262-00	SEAL	1
53	330004-06	BEARING,NEEDLE	2
54	384199-00	ROD,CONTROL	1
55	448809-00	KNOB	1
56	604892-00	SPRING	2
57	000475-00	BALL	2

## Parts List for DW317K-B2 Type 2

Item Number	Part Number	Description	Qty Required
58	384198-00	RING,RETAINING	1
59	449192-00	TERMINAL	2
60	605040-15	BALL BEARING	1
61	330003-04	BEARING,BALL	1
62	445874-00	BRG. RETAINER	1
63	445857-03	CASE,FIELD	1
64	618913-01SV	FIELD	1
65	449899-05	RING,BRUSH	1
66	445860-00	SPRING,BRUSH	2
67	445880-00	SCREW	2
68	444793-00	RING, RETAINING	1
800	761995-01	GREASE, 6 OZ.	1
800	283484-01	GREASE,32 OZ.	1
861	660506-00	KIT BOX	1
862	629053-00	TOOL BAG	1