



Parts List for DW318K Type 1

Item Number	Part Number	Description	Qty Required
1	5140006-40	ARMATURE&FIELD	1
2	5140006-40	ARMATURE&FIELD	1
3	445861-25	BRUSH	2
4	445860-00	SPRING,BRUSH	2
5	449899-05	RING,BRUSH	1
6	445880-00	SCREW	2
7	380733-00	SWITCH	1
8	330072-98	CORD/8FT/18-2SJ	1
9	330003-04	BEARING,BALL	1
10	330003-08	BEARING,BALL	1
11	395047-00	ID LABEL	1
12	603209-00	HANDLE SET	1
14	449192-00	TERMINAL	2
15	444793-00	RING, RETAINING	1
16	445874-00	BRG. RETAINER	1
17	099056-04	HEX WRENCH	1
18	098000-11	WRENCH	1
19	445857-03	CASE,FIELD	1
22	000000-00	No Longer Available	1
23	330005-01	PROTECTOR,CORD	1
24	330019-13	SCREW,M4X19	1
26	330045-08	SCREW	2
27	000000-00	No Longer Available	1
28	330019-27	SCREW,TORX	2
29	400765-00	GUIDE	1
30	133825-00	RING	1
31	330019-14	SCREW	7

Parts List for DW318K Type 1

Item Number	Part Number	Description	Qty Required
32	445876-00	BAFFLE, FAN	1
33	608389-00	BRACKET	1
34	445217-02	SLEEVE	1
36	445405-00	SCREW,SET	1
37	330022-16	SCREW	1
38	444520-00	BLADE CLAMP	1
40	133751-00	SHIELD	1
41	133755-00	SEAL	1
42	133820-00	PIN	1
43	133847-00	FELT OILER	1
44	133750-00	CLAMP	1
45	049161-00	SPRING	1
46	133756-00	BEARING,SLEEVE	1
47	445387-00	YOKE BAR	1
48	450285-00	SEAL PLATE	1
49	133807-00	SEAL	1
50	098022-26	SCREW	2
51	620203-00	ROLLER	1
52	133844-00	RETAINER	1
53	330045-05	LOCK SCREW	1
54	133828-01SV	CRANK PLATE	1
55	133765-00	GASKET	1
56	133761-00	WEIGHT	1
57	429882-64	ROD	1
58	098185-20	PIN	1
59	330015-07	NUT,HEX	1
60	133799-00	FORK	1

Parts List for DW318K Type 1

Item Number	Part Number	Description	Qty Required
61	098198-05	WASHER	1
62	133827-02SV	GEAR & BEARING	1
63	448817-02	GEAR CASE	1
64	133770-00	SHOE	1
65	445687-00	WASHER	2
66	000000-00	No Longer Available	1
67	000475-00	BALL	2
68	604892-00	SPRING	2
69	448809-00	KNOB	1
70	098121-31	SCREW	1
72	330004-06	BEARING,NEEDLE	2
73	449977-00	QUADRANT	1
74	080164-00	SCREW	1
80	065288-02	HOLDER	1
800	761995-01	GREASE, 6 OZ.	1
801	283484-01	GREASE,32 OZ.	1
846	000000-00	No Longer Available	1
861	393455-00	KIT BOX	1