





Parts List for DW616D Type 1

Item Number	Part Number	Description	Qty Required
1	396310-00	MOTOR HOUSING	1
2	146555-01	BEARING, BALL	1
3	394219-00	CLAMP NUT	1
4	398221-00SV	ARMATURE & BRG.	1
5	330045-57	SCREW	3
6	399064-00	TOGGLE SWITCH	1
7	399028-00	SWITCH BOOT	1
8	397500-00	RECEPTACLE	1
9	397501-00	WIRE GUARD	1
10	397564-00	END CAP	1
11	033055-00	PLUG	1
12	330045-09	SCREW	4
13	150036-00	SCREW,GROUND	1
14	399063-00	CORDSET	1
15	330003-09	BEARING,BALL	1
16	053650-03	TERMINAL	1
17	608552-00	GROUND WIRE	1
18	608551-00	LEADWIRE	1
19	397566-01	BRUSH RING ASM	1
20	398139-01	BRUSH ASSY.	2
21	397569-00SV	FIELD	1
22	330019-27	SCREW,TORX	2
23	398216-00	FIELD CASE	1
24	5140060-14	COLLET & NUT	1
24	326286-03	COLLET & NUT	1
24	326286-04	COLLET & NUT	1
25	399068-00	WRENCH	2

Parts List for DW616D Type 1

Item Number	Part Number	Description	Qty Required
26	612616-00	NAME PLATE	1
34	607523-00	SUB BASE ALIGN. CONE	1
35	607522-00	BASE ALIGN. SHAFT	1
300	397408-00	BASE	1
301	330041-45	ROLL PIN	3
302	330021-01	NUT,STOP	1
303	606623-00	SPACER	1
304	397531-01	SUB BASE	1
304	397531-00	SUB BASE	1
305	609842-00	SCREW	4
306	397406-00	LATCH RELEASE	2
307	397411-00	SPRING	2
308	330041-44	ROLLER PIN	2
309	397503-00	CLAMP LEVER	1
310	397504-00	THREADED ROD	1
311	397450-00	ID LABEL	1
312	397560-00	KNOB	1
313	607395-00	SCREW	1
314	098197-09	LOCKWASHER	1
315	611827-00	HANDLE & COVER	1
316	399063-01	CORD SET	1
317	606438-00	CORD PROTECTOR	1
318	381065-00	CORD CLAMP	1
319	330019-11	SCREW	3
320	389524-01	SWITCH	1
321	384127-01	SCREW	4
322	397500-00	RECEPTACLE	1

Parts List for DW616D Type 1

Item Number	Part Number	Description	Qty Required
323	150036-00	SCREW,GROUND	2
324	607560-00	LEAD WIRE ASSY	1
325	607560-01	LEAD WIRE ASSY	1
326	607560-02	LEAD WIRE ASSY	1
327	330019-13	SCREW,M4X19	3
328	330019-16	SCREW	2
329	396311-00	ADJUSTING RING	1
330	612054-00	ADJUSTING RING	1
331	397451-01	LABEL	1