



Parts List for DWE575SB Type 1

Item Number	Part Number	Description	Qty Required
1	N227899	ARMATURE & BRGS	1
2	N097330	FIELD	1
3	652811-00	BRUSH ASSEMBLY	2
4	145347-00	LEVER,LOCK	1
5	145344-00	SCREW,SPECIAL	1
6	145343-01	CLAMP,OUTER BLD	1
7	98128-90	CARRIAGE BOLT	2
8	381066-00	BUMPER	1
9	384127-01	SCREW	4
10	N082690	BLADE WRENCH	1
11	N219393	SPINDLE & GEAR ASSY.	1
12	N237899	GEAR CASE ASSY.	1
13	N100358	O-RING	1
14	330003-64	BALL BEARING	1
15	330003-60	BEARING	1
16	N136311	BOOT	1
17	N084137	CLAMP WASHER	1
18	N084715	SHOE ASSEMBLY	1
19	N086135	SHOULDER SCREW	1
20	N090570	LOCK LEVER	1
21	N090678	END CAP	1
22	N120420	SWITCH	1
23	N090889	FIELD CASE	1
24	N094731	SCREW	1
25	N099101	BOLT	1
26	N100006	TORSION SPRING	1
27	N100123	TORSION SPRING	1

Parts List for DWE575SB Type 1

Item Number	Part Number	Description	Qty Required
28	N115554	AUXILIARY HANDLE	1
29	N117921	STOP NUT	1
30	N123095	FAN BAFFLE	1
31	330005-02	PROTECTOR, CORD	1
32	330019-13	SCREW,M4X19	9
33	330079-98	CORD/10FT/14-2SJ	1
34	395716-00	TERMINAL	1
35	N095539	CORD CLAMP	1
36	N127730	CORD CLAMP	1
37	N188194	HOUSING ASSEMBLY	1
38	N188194	HOUSING ASSEMBLY	1
39	N135988	STRAP	1
40	N152487	NAMEPLATE	1
41	N152743	LOWER GUARD	1
42	098094-13	SCREW	1
43	N094953	GUARD LEVER	1
44	N146857	WASHER	1
45	N123103	STOP NUT	1
46	145332-00	TERMINAL	1
47	385915-04	SCREW	4
48	330019-18	SCREW,PLASTITE	2
49	330045-19	SCREW	1
50	330045-21	SCREW	3
51	330019-10	SCREW	2
52	330019-45	SCREW	4
53	593515-00	SCREW,PLASTITE	1
54	N120426	RETAINING RING	1

Parts List for DWE575SB Type 1

Item Number	Part Number	Description	Qty Required
55	056122-00	O-RING	1
800	429954-01	GREASE,1 LB.	1
800	429954-00	GREASE, 7LBS	1
846	605265-00	SPRING CLIP	1
846	N135093	BLADE HOLDER	1
862	629053-00	TOOL BAG	1