





#1 - BELTGUARD OUTER,Qty Req in Model: 1
Part #: 5140236-26**Description:** BELTGUARD OUTER

#2 - SPRING,Qty Req in Model: 4
Part #: 5140235-62**Description:** SPRING

#3 - SCREW,Qty Req in Model: 7
Part #: 5140235-73**Description:** SCREW

#4 - BELTGUARD INNER,Qty Req in Model: 1
Part #: 5140236-27**Description:** BELTGUARD INNER

#7 - BELT,Qty Req in Model: 1
Part #: 5140236-28**Description:** BELT

#8 - PULLEY,Qty Req in Model: 1
Part #: 5140236-29**Description:** PULLEY

#9 - CORD,Qty Req in Model: 1
Part #: 5140236-30**Description:** CORD

#10 - SCREW,Qty Req in Model: 5
Part #: 5140235-82**Description:** SCREW

#11 - NUT,Qty Req in Model: 5
Part #: 5140235-83**Description:** NUT

#12 - BUSHING,Qty Req in Model: 1
Part #: 5140169-40**Description:** BUSHING

#12 - O-RING,Qty Req in Model: 2
Part #: 5140169-41**Description:** O-RING

#12 - BUSHING,Qty Req in Model: 1
Part #: 5140169-42**Description:** BUSHING

#12 - DRAIN VALVE,Qty Req in Model: 1
Part #: 5140236-31**Description:** DRAIN VALVE

#13 - PUMP,Qty Req in Model: 1
Part #: 5140236-32**Description:** PUMP

#15 - COMPRESSION NUT,Qty Req in Model: 2
Part #: 5140236-33**Description:** COMPRESSION NUT

#16 - NUT,Qty Req in Model: 1
Part #: 5140235-91**Description:** NUT

#17 - OUTLET TUBE,Qty Req in Model: 1
Part #: 5140236-34**Description:** OUTLET TUBE

#18 - PRESSURE RELIEF TUBE,Qty Req in Model: 1
Part #: 5140236-35**Description:** PRESSURE RELIEF
TUBE

#19 - VALVE,Qty Req in Model: 1
Part #: 5140235-88**Description:** VALVE

#20 - PRESSURE SWITCH,Qty Req in Model: 1
Part #: 5140169-46**Description:** PRESSURE SWITCH

#22 - SAFETY VALVE,Qty Req in Model: 1
Part #: 5140169-22**Description:** SAFETY VALVE

#23 - PRESSURE GAUGE,Qty Req in Model: 1
Part #: 5140169-12**Description:** PRESSURE GAUGE

#24 - CAPACITOR COVER,Qty Req in Model: 1
Part #: 5140236-19**Description:** CAPACITOR COVER

#24 - START CAP COVER,Qty Req in Model: 1
Part #: 5140236-20**Description:** START CAP COVER

#24 - RUN CAPACITOR,Qty Req in Model: 1
Part #: 5140236-64**Description:** RUN CAPACITOR

#24 - START CAPACITOR,Qty Req in Model: 1
Part #: 5140236-65**Description:** START CAPACITOR

#24 - MOTOR,Qty Req in Model: 1
Part #: 5140236-66**Description:** MOTOR

#24 - RUN CAPACITOR,Qty Req in Model: 1
Part #: 5140236-67**Description:** RUN CAPACITOR

#24 - START CAPACITOR,Qty Req in Model: 1
Part #: 5140236-68**Description:** START CAPACITOR

#24 - COVER,Qty Req in Model: 1
Part #: 5140236-69**Description:** COVER

#24 - COVER,Qty Req in Model: 1
Part #: 5140236-70**Description:** COVER

#25 - BRACKET,Qty Req in Model: 1
Part #: 5140236-36**Description:** BRACKET

#26 - SCREW,Qty Req in Model: 4
Part #: 5140235-84**Description:** SCREW

#27 - ISOLATOR PAD,Qty Req in Model: 1
Part #: 5140236-37**Description:** ISOLATOR PAD

#28 - BRACKET,Qty Req in Model: 1
Part #: 5140236-38**Description:** BRACKET

#30 - LABEL-HOT SURFACE,Qty Req in Model: 1
Part #: 5140230-38**Description:** LABEL-HOT SURFACE

#31 - WARNING LABEL,Qty Req in Model: 1
Part #: 5140168-84**Description:** WARNING LABEL

#32 - SCREW KIT,Qty Req in Model: 2
Part #: 5140230-58**Description:** SCREW KIT

#33 - FLYWHEEL,Qty Req in Model: 1
Part #: 5140237-78**Description:** FLYWHEEL

#34 - SCREW,Qty Req in Model: 4
Part #: 5140235-61**Description:** SCREW

#846 - ISOLATOR PAD,Qty Req in Model: 4
Part #: 5140235-93**Description:** ISOLATOR PAD

#101 - AIR FILTER ASSY,Qty Req in Model: 3
Part #: 5140236-40**Description:** AIR FILTER ASSY.

#102 - HEAD PUMP,Qty Req in Model: 1
Part #: 5140236-41**Description:** HEAD PUMP

#103 - BREATHER PLUG,Qty Req in Model: 1
Part #: 5140236-42**Description:** BREATHER PLUG

#104 - OIL FILL PLUG,Qty Req in Model: 1
Part #: 5140236-43**Description:** OIL FILL PLUG

#105 - OIL SIGHT GLASS,Qty Req in Model: 1
Part #: 5140236-44**Description:** OIL SIGHT GLASS

#106 - HEAD GASKET,Qty Req in Model: 3
Part #: 5140236-45**Description:** HEAD GASKET

#107 - CYLINDER GASKET,Qty Req in Model: 3
Part #: 5140236-46**Description:** CYLINDER GASKET

#108 - CRANKCASE GASKET,Qty Req in Model: 3
Part #: 5140236-47**Description:** CRANKCASE GASKET

#109 - CROSSOVER TUBE,Qty Req in Model: 1
Part #: 5140236-48**Description:** CROSSOVER TUBE

#110 - LOCK WASHER,Qty Req in Model: 1
Part #: 5140170-77**Description:** LOCK WASHER

#111 - NUT,Qty Req in Model: 4
Part #: 5140236-50**Description:** NUT

#112 - TEE FITTING,Qty Req in Model: 1
Part #: 5140236-51**Description:** TEE FITTING

#113 - TEE FITTING,Qty Req in Model: 1
Part #: 5140236-52**Description:** TEE FITTING

#114 - ELBOW,Qty Req in Model: 1
Part #: 5140236-53**Description:** ELBOW

#115 - VALVE PLATE ASSEMBLY,Qty Req in Model: 3
Part #: 5140236-54**Description:** VALVE PLATE
ASSEMBLY

#116 - HEAD BOLT,Qty Req in Model: 3
Part #: 5140236-55**Description:** HEAD BOLT

#117 - BOLT,Qty Req in Model: 1
Part #: 5140236-56**Description:** BOLT

#118 - WASHER,Qty Req in Model: 1
Part #: 5140170-76**Description:** WASHER

#119 - OIL DRAIN PLUG,Qty Req in Model: 1
Part #: 5140236-58**Description:** OIL DRAIN PLUG

#120 - STUD,Qty Req in Model: 3
Part #: 5140236-59**Description:** STUD

#121 - LOCK WASHER,Qty Req in Model: 3
Part #: 5140236-60**Description:** LOCK WASHER

#122 - NUT,Qty Req in Model: 3
Part #: 5140236-61**Description:** NUT

#123 - FITTING,Qty Req in Model: 1
Part #: 5140236-62**Description:** FITTING

#124 - KEY,Qty Req in Model: 1
Part #: 5140236-63**Description:** KEY