


# GASOLINE POWERED ROTARY HAMMER 'SPLINE' ER-382K




## PARTS LIST FOR AFTER SALES SERVICE MODEL ER382K

R	PART NO.	DESCRIPTION	QTY	REF	PART NO.	DESCRIPTION	QTY
1	2140616	SCREW	3	44	6750023	NEEDLE BEARING	1
2	2900001	BUSH	3	45	6100245	CRANKSHAFT	1
3	2360006	FUEL TANK GUARD	1	46	6100231	PARALLEL KEY	1
4	2550001	STOP SWITCH	1	47	2320001	CRANKCASE	1
5	2920058	GASOLINE LABEL	1	48	2930001	O-RING	1
6	2430072	CLAMP	1	49	9846004	BALL BEARING #6004LLB	1
7	2150002	AIR CLEANER GUARD	1	50	9524200	RETAINING RING R42	1
8	9550600	SPRING WASHER M6	13	51	9512000	RETAINING RING S20	1
9	9020616	SCREW	2	52	2200002	CRANKSHAFT GEAR	1
10	9020418	SCREW	1	53	9511400	RETAINING RING S14	1
11	2360085	OVERFLOW PIPE	1	54	9911210	NEEDLE BEARING	2
12	2920054	MODEL NAME LABEL	1	55	2200001	DRIVE GEAR	1
13	2140512	SCREW	2	56	9846201	BALL BEARING #6201LLB	1
14	2360003	FAN CASE COVER	1	57	9523200	SNAP RING R32	1
15	2920004	PLACING INSTRUCTION LABEL	1	58	2930002	OIL SEAL	1
16	2830002	HANDLE (R)	1	59	2090001	CLUTCH DRUM	1
17	9550600	SPRING WASHER M5	2	60	6370204	RUBBER CUSHION	1
18	9220525	HEX SOCKET HEAD BOLT M5X25	2	61	6130465	TIGHTENING BOLT	1
19	2360005	TRIGGER	1	62	6320151	HANDLE CLAMP (B)	1
20	2120001	THROTTLE WIRE HOLDER	1	63	6290059	STEEL BALL 5/16"	3
21	2060004	ENGINE	1	64	6220118	ADAPTER	1
22	2360004	BUTTON	1	65	6290055	STEEL BALL 5/32"	1
23	9000420	PHILLIPS PAN SCREW M4X20	1	66	6100243	PARALLEL KEY	2
24	830001	HANDLE (L)	1	67	6080168	CYLINDER ASSEMBLY	1
26	2180001	SPRING	1	68	6830999	SIDE HANDLE ASSEMBLY	1
27	9405020	SPRING PIN	1	69	6180205	COIL SPRING	1
28	2120002	STOP PIN	1	70	6320146	HANDLE CLAMP (A)	1
29	9000410	PHILLIPS PAN SCREW M4X10	1	71	9405018	SPRING PIN	1
30	9550800	SPRING WASHER M8	1	72	6120142	CONNECTING ROD PIN	1
31	2130001	BOLT	1	73	9220625	HEX SOCKET HEAD BOLT M6X25	7
32	2370001	HANDLE GRIP	1	74	6320141	BARREL	1
33	2130002	HEX SOCKET HEAD BOLT M6X80	2	75	9914516	NEEDLE BEARING	1
34	9220620	HEX SOCKET HEAD BOLT M6X20	4	76	6200272	BEVEL GEAR	1
35	2920003	BRAND MARK LABEL	2	77	6180214	SPRING	1
36	2050001	MIDDLE GEAR ASSEMBLY	1	78	6220112	HAMMER	1
37	9846200	BALL BEARING #6200LLB	1	79	6930083	O-RING	2
38	2320002	GEAR CASE	1	80	6320152	PISTON	1
39	6360198	OIL CAP	1	81	6080169	FRONT CAP ASSEMBLY	1
41	9511200	RETAINING RING S12	1	82	2920049	ENGINE INSTRUCTION LABEL	1
42	6220121	CONNECTING ROD PLATE	1	83	2920061	FUEL CAUTION LABEL	1
43	6190142	CONNECTING ROD	1	84	2920044	BAR CORD SEAL	1


**PARTS LIST FOR AFTER SALES SERVICE  
MODEL ER382K - CONTROL SYSTEM**

REF	PART NO.	DESCRIPTION	QTY	REF	PART NO.	DESCRIPTION	QTY
1	2380050	WIRE & THROTTLE	1	2	2380051	CAP	1




**PARTS LIST FOR AFTER SALES SERVICE  
MODEL ER382K - MUFFLER SYSTEM**

REF	PART NO.	DESCRIPTION	QTY	REF	PART NO.	DESCRIPTION	QTY
1	2141408	SCREW & WASHER	2	5	2380060	MUFFLER	1
2	2380068	MUFFLER COVER	1	6	2380061	MUFFLER GASKET	1
3	9310500	NUT	1	7	2140508	SCREW	1
4	2380059	LOCK WASHER	1	8	2140416	SCREW & WASHER	1




## PARTS LIST FOR AFTER SALES SERVICE MODEL ER382K - CRANKCASE SYSTEM

REF	PART NO.	DESCRIPTION	QTY	REF	PART NO.	DESCRIPTION	QTY
1	2380000	CRANKCASE ASSEMBLY	1	8	2380003	SCREW & WASHER	1
2	9020630	SCREW	4	9	9523200	SNAP RING R32	1
3	9020408	SCREW & WASHER	2	10	2380004	CRANKCASE GASKET	1
4	2380001	BRACKET	1	11	9806201	BALL BEARING #6201	1
5	9000520	PHILLIPS PAN SCREW M5X20	4	12	9806001	BALL BEARING #6001	1
6	2380002	CLAMP	1	13	2430037	OIL SEAL	1
7	9020508	SCREW	1				




## PARTS LIST FOR AFTER SALES SERVICE MODEL ER382K - CYLINDER & HEAD SYSTEM

REF	PART NO.	DESCRIPTION	QTY	REF	PART NO.	DESCRIPTION	QTY
1	2141512	SCREW & WASHER	1	4	2430047	BOLT & WASHER	4
2	2380005	CYLINDER COVER	1	5	2380007	BOLT STUD	2
3	2380006	CYLINDER	1	6	2380008	CYLINDER GASKET	1




**PARTS LIST FOR AFTER SALES SERVICE  
MODEL ER382K - CLUTCH SYSTEM**

REF	PART NO.	DESCRIPTION	QTY	REF	PART NO.	DESCRIPTION	QTY
1	2380358	CLUTCH SHOE	2	4	2430214	CLUTCH	1
2	2380062	SPRING	1	5	2380063	WASHER	2
3	2430156	CLUTCH BOLT	2				




**PARTS LIST FOR AFTER SALES SERVICE  
MODEL ER382K - FUEL TANK SYSTEM**

REF	PART NO.	DESCRIPTION	QTY	REF	PART NO.	DESCRIPTION	QTY
1	2430048	CLIP	2	6	2380092	TANK CAP ASS'Y	1
2	2360087	FUEL TUBE	1	7	2380098	PAD	2
3	2380078	PRIMING PUMP	1	8	2360007	FUEL TANK	1
4	2380098	SUCTION HOSE	1	9	2130003	SCREW & WASHER	2
5	2380089	FUEL FILTER	1				




**PARTS LIST FOR AFTER SALES SERVICE  
MODEL ER382K - AIR CLEANER SYSTEM**

REF	PART NO.	DESCRIPTION	QTY	REF	PART NO.	DESCRIPTION	QTY
1	2380052	AIR CLEANER	1	4	2380054	CHOKE LABEL	1
2	2140425	SCREW & WASHER	2	5	2380055	AIR CLEANER ELEMENT	1
3	2380053	CLEANER COVER	1	6	2380057	ELEMENT HOLDER	1




**PARTS LIST FOR AFTER SALES SERVICE  
MODEL ER382K - RECOIL STARTER SYSTEM**

REF	PART NO.	DESCRIPTION	QTY	REF	PART NO.	DESCRIPTION	QTY
1	2140412	SCREW & WASHER	1	8	2380070	RETURN SPRING	1
2	2380064	RECOIL STARTER	1	9	2380071	SCREW	1
3	2380065	CRANKCASE GASKET	1	10	2380072	PLATE	1
4	2380066	STARTER PULLEY	1	11	2380073	RATCHET	1
5	2380067	SPIRAL SPRING	1	12	2380074	KNOB STARTER	1
6	2380068	REEL ASS'Y	1	13	2380075	STARTER ROPE	1
7	2380069	FRICTION SPRING	1				




## PARTS LIST FOR AFTER SALES SERVICE MODEL ER382K - CARBURETOR SYSTEM

REF	PART NO.	DESCRIPTION	QTY	REF	PART NO.	DESCRIPTION	QTY
1	2380021	GASKET CARBURETOR	1	17	2380037	HIGH SPEED ADJUST SCREW	1
2	2380022	INSULATOR	1	18	2380038	SPRING	1
3	2380023	GASKET CARBURETOR	1	19	2380039	GASKET	1
4	2380024	SCREW & WASHER	2	20	2380040	GASKET PUMP COVER	1
5	2380025	SCREW & WASHER	2	21	2380041	DIAPHRAGM PUMP	1
6	2380026	CARBURETOR (D)	1	22	2380042	COVER	1
7	2380027	WIRE HOLDER	1	23	9020312	SCREW	4
8	2380028	NUT	1	24	2380043	NEEDLE VALVE	1
9	2380029	CAP	1	25	2380044	FLOAT ARM	1
10	2380030	THROTTLE RETURN SPRING	1	26	2380045	FLOAT PIN	1
11	2380031	CLIP NEEDLE	1	27	2380046	SCREW FLOAT PIN SET	1
12	2380032	SPRING RETAINER	1	28	2380047	DIAPHRAGM	1
13	2380033	JET NEEDLE	1	29	2380048	DIAPHRAGM COVER	1
14	2380034	THROTTLE VALVE	1	30	9020308	SCREW	4
15	2380035	IDLE ADJUST SPRING	1	31	2380049	AIR CLEANER GASKET	1
16	2380036	IDLE ADJUST SCREW	1				



**PARTS LIST FOR AFTER SALES SERVICE  
MODEL ER382K - CRANKSHAFT & PISTON SYSTEM**

PART NO.	DESCRIPTION	QTY	REF	PART NO.	DESCRIPTION	QTY
2380015	PISTON SET	1	5	2380019	TOP RING	
2380016	PISTON PIN	1	6	6100257	WOODRUFF KEY	
2380017	CLIP PISTON PIN	2	7	2430457	CONICAL SPRING NUT	
2380018	BEARING NEEDLE	1	8	2380020	CRANKSHAFT ASSEMBLY	



**PARTS LIST FOR AFTER SALES SERVICE  
MODEL ER382K - FLYWHEEL MAGNETO SYSTEM**

REF	PART NO.	DESCRIPTION	QTY	REF	PART NO.	DESCRIPTION	QTY
1	2430047	BOLT & WASHER	2	6	2380013	SPARK PLUG CAP	
2	2380009	IGNITION COIL	1	7	2430032	SPARK PLUG	
3	2380010	DUST SEAL BUSH	1	8	2380014	UNIT	
4	2380011	FLYWHEEL	1	9	9020408	SCREW & WASHER	
5	2380012	DUST SEAL BUSH	1				

