



## Parts List for ET1215 Type 1

Item Number	Part Number	Description	Qty Required
1	448583-31	ARMATURE	1
2	447864-05	FIELD	1
3	445861-25	BRUSH	2
4	445860-00	SPRING,BRUSH	2
5	449899-05	RING,BRUSH	1
7	380786-00	SWITCH	1
8	330072-98	CORD/8FT/18-2SJ	1
9	330003-04	BEARING,BALL	2
11	449829-00	NUT, FIELD	2
13	055206-00	SCREW	1
14	133042-00	SCREW	2
15	330019-05	SCREW,PLASTITE	8
16	330019-03	SCREW	3
17	448269-00	SCREW	2
18	445881-99	STRIP,CONTACT	2
19	449192-00	TERMINAL	2
25	330003-09	BEARING,BALL	1
27	030611-00	PLUG	1
28	095114-00	RUBBER PLUG	1
29	445402-00	PAD, RUBBER	1
30	448596-01	HOUSING	1
31	449857-00	CASE, GEAR	1
32	449033-01	CASE, GEAR	1
32	449033-01	CASE, GEAR	1
33	131557-00	BEARING,SLEEVE	1
34	448591-00	COVER,GEAR CASE	1
35	445175-00	BEARING, SLEEVE	1

## Parts List for ET1215 Type 1

Item Number	Part Number	Description	Qty Required
37	429663-00	CHUCK & KEY	1
38	330034-02	CHUCK KEY	1
39	445414-01SV	GEAR & SPINDLE	1
40	445397-03SV	GEAR & PINION	1
42	445217-02	SLEEVE	1
43	448595-04	PADDLE	1
45	330005-01	PROTECTOR,CORD	1
47	000000-00	No Longer Available	1
48	388263-00	LABEL,IDENT	1
53	065288-01	CH KEY HOLDER	1
55	448373-00	WASHER,SPRING	1
56	447765-00	WASHER, FLAT	1
61	385257-00	SPRING	1
800	761995-01	GREASE, 6 OZ.	1
801	283484-01	GREASE,32 OZ.	1