


EXPLODED VIEW



REPLACEMENT PARTS LIST

Ref. No.	Part No.	Part Name & Descriptions	Par set	Remarks
1	EY503H3228	Clutch handle	1	
2	EY503B0637	Adjust ring	1	
3	EY503B0167	Clutch spring	1	
4	EY503B0847	Thrust plate	1	
5	EY503B0397	Clutch pin	3	
6	EY503B1917	Ball bearing	7	
7	EY503B1458	Gear box	1	
8	EY503B1007	DC motor	1	
9	EY503Y2008	Switch	1	
10	EY503B3079	Housing AB set	1	
11	EY503B9167	Tapping screw for housing	4	
12	EY503H3238	Change-gear handle	1	
13	EY502B0187	Click spring	2	
14	EY502B6217	Tapping screw for grip	1	
15	EY503H6248	Decorative washer	1	
16	EY503H6348	Fastening nut	1	
17	EY502B0877	Hinge cover	1	
18	EY503B3938	Grip	1	
19	EY903B	Battery pack	1	available as an optional accessory
20	EY502B7907	Bit holder	1	
21	EY503B3098	Charger housing A	1	
22	EY503B3028	Charger housing B	1	
23	EY503B2128	Module (PC board with component)	1	
24	EY503B2238	Power transformer	1	
25	EY503B2058	Power cord	1	
26	EY78339067	Tapping screw for charger	3	
27	EY503B7658	Charging adaptor (Complete)	1	available as an optional accessory
28	EY502B7927	#1 Phillips bit	1	
29	EY502B7957	#2 Phillips bit	1	
30	EY502B7937	Slotted head bit	1	