



Parts List for FS12PSK Type 1

Item Number	Part Number	Description	Qty Required
1	149518-01	SCREW	1
2	419233-10	KEYLESS CHUCK	1
3	90504405	TRANSMISSION ASSY.	1
4	90504417	FORWARD/REV SELECTOR	1
5	90502293	SCREW	1
6	90504142	NAMEPLATE	1
7	497283-02	SCREW	3
8	5106167-00	SCREW	2
9	5146421-00	SCREW	2
10	90534262	MOTOR & PINION	1
11	90504416	CLAMSHELL SET	1
12	148354-03	BIT CLIP	1
13	419581-01	BIT	1
14	90504402	REAR COVER	1
15	046376-00	PIN	1
16	90504310	SWITCH,DC,VSR	1
19	5100035-03	SPRING	2
20	5100034-00	TERMINAL BLOCK	1
861	5102001-10	KITBOX	1
866	FS120BX	BATTERY PACK	1
867	5102026-00	BATTERY CAP	1
871	90500928	CHARGER	1