



## Parts List for FS14PSK Type 1

| Item Number | Part Number | Description          | Qty Required |
|-------------|-------------|----------------------|--------------|
| 1           | 149518-01   | SCREW                | 1            |
| 2           | 90506740    | KEYLESS CHUCK        | 1            |
| 3           | 90504426    | MOTOR & GEARBOX      | 1            |
| 4           | 90504417    | FORWARD/REV SELECTOR | 1            |
| 5           | 90502293    | SCREW                | 1            |
| 6           | 90504143    | NAMEPLATE            | 1            |
| 7           | 497283-02   | SCREW                | 3            |
| 8           | 5106167-00  | SCREW                | 2            |
| 9           | 5146421-00  | SCREW                | 2            |
| 11          | 90504416-01 | CLAMSHELL SET        | 1            |
| 12          | 148354-03   | BIT CLIP             | 1            |
| 13          | 419581-01   | BIT                  | 1            |
| 14          | 90504402    | REAR COVER           | 1            |
| 15          | 046376-00   | PIN                  | 1            |
| 16          | 90504359    | SWITCH,VSR           | 1            |
| 19          | 5100035-03  | SPRING               | 2            |
| 20          | 5100034-00  | TERMINAL BLOCK       | 1            |
| 861         | 5102001-10  | KITBOX               | 1            |
| 866         | FSB14       | BATTERY              | 2            |
| 867         | 5102026-00  | BATTERY CAP          | 2            |
| 871         | 5103069-09  | CHARGER ASSY.        | 1            |