



867



866

871



Parts List for FS18SW Type 1

Item Number	Part Number	Description	Qty Required
866	90503508	BATTERY PACK	1
867	5102026-00	BATTERY CAP	1
871	5103069-12	CHARGER	1