


FLEX



No.	Product Model#	Part Number	Description	Qty
1	FX1271T-Z	2827543002	Auxiliary Handle Assembly	1
2	FX1271T-Z	2827567002	L R Housing Set	1
3	FX1271T-Z	5610241002	Screw	12
4	FX1271T-Z	3127743001	Bit Holder	1
5	FX1271T-Z	3322885001	Rear Cover	1
6	FX1271T-Z	2751339002	Rotor Set	1
7	FX1271T-Z	2827806002	Stator and Electronic Components	1
9	FX1271T-Z	5610248003	Tapping Screw	4
10	FX1271T-Z	3131367001	F/R Button	1
11	FX1271T-Z	3127733001	LED Cover	1
12	FX1271T-Z	3707607001	Indicator Label	1
13	FX1271T-Z	3131420001	Switch Button Cover	1
14	FX1271T-Z	5620039010	Screw	2
15	FX1271T-Z	3707622001	Buckle	1
201	FX1271T-Z	2828455001	Gear Box and Chuck Assembly	1
8	FX1271T-Z	5610400001	Hexalobular Socket Raised Countersunk Head Screw	1