



## Parts List for G-TS300 Type 2

Item Number	Part Number	Description	Qty Required
1	91903-10	COVER,SWITCH	1
4	000000-00	No Longer Available	1
5	157312-00	SCREW,SPEC.,LH	1
6	000000-00	No Longer Available	1
7	037381-00	WASHER	2
8	157315-00	WASHER,SPRING	1
9	000000-00	No Longer Available	1
13	10511-00	BEARING,THRUST	1
14	000000-00	No Longer Available	2
15	000000-00	No Longer Available	1
16	000000-00	No Longer Available	1
18	000000-00	No Longer Available	1
19	85894-00	BEARING,SLEEVE	1
20	85899-00	BEARING,SLEEVE	2
21	000000-00	No Longer Available	1
22	330075-25	KEYLESS CHUCK	1
25	330073-96	CORD/8'/18-2SJT	1
26	000000-00	No Longer Available	1
27	085931-00	BEARING	1
28	000000-00	No Longer Available	1
29	330019-13	SCREW,M4X19	1
30	000000-00	No Longer Available	2
31	000000-00	No Longer Available	2
33	000000-00	No Longer Available	2
34	134252-00	HOLDER,BRUSH	2
35	000000-00	No Longer Available	1
38	000000-00	No Longer Available	1

## Parts List for G-TS300 Type 2

Item Number	Part Number	Description	Qty Required
39	85909-00	BEARING,SLEEVE	1
41	000000-00	No Longer Available	1
42	32114-06	CONNECTOR	1
800	429698-00	GREASE:4 LB CAN	1
856	000000-00	No Longer Available	1