











































Parts Breakdown

G1300R

Products with multiple versions are listed in subsiding order with the newest version on top not indented

<u>Fig #</u>	<u>Part ID</u>	<u>Part Name</u>	<u>Quantity</u>
1	350-22808-11	STATOR CPL.,G1300R	1
2	350-24301-01	ROTOR CP., G1300R	1
3	358-21015-08	BALL BEARING, G1300R	1
4	358-21020-08	CONNECTOR(6P), G1300R .	1
5	350-21320-08	CONDENSER, G1300R	1
6	376-22100-03	CONDENCER BRACKET, G1300R	1
7	358-21006-08	RECTIFIER, G1300R	1
8	383-21051-08	SCREW, G1300R	4
9	350-21300-08	REAR BRACKET, G1300R	1
10	056-30000-20	WIRE BAND, G2400R	1
11	376-23000-03	FRONT COVER, G1300R	1
12	350-23501-01	END COVER COMPLETE, G1300R	1
13	377-24000-13	STATOR COVER, G1300R	1
14	377-25100-03	THROUGH BOLT, G1300R	1
15	377-25200-03	COVER BOLT, G1300R	3
16	003-11080-00	WASHER, G1300R	1
17	001-13082-00	BOLT & WASHER, G2410R .	4
18	004-36040-80	SCREW & WASHER ASS'Y, G1300R	3
19	350-30103-01	MOUNT COMPLETE, G1300R	2
20	002-38080-00	FLANGE NUT, G6100R	2
21	350-30103-01	MOUNT COMPLETE, G1300R	1
22	350-30104-01	MOUNT COMPL. G1300R	1
23	350-30701-21	MOUNT BRACKET COMPL. G1300R	1
24	350-35101-11	BRACKET COMPLETE, G1300R	1
25	001-13082-00	BOLT & WASHER, G2410R .	2
26	002-38080-00	FLANGE NUT, G6100R	3
27	350-50307-01	FRONT COVER, G1300R	1
28	350-50707-01	REAR COVER CPL.,G1300R	1
29	350-51707-01	SIDE COVER, G1300R	1
31	013-10500-20	SCREW & WASHER ASS'Y, G1300R	8
32	004-34051-00	SCREW & WASHER ASS'Y, G1300R	2
33	004-31081-00	PAN HEAD SCREW, G1300R	2
34	003-11080-00	WASHER, G1300R	2
35	350-44113-01	CONTROL PANEL CPL.,G1300R	1
36	352-45620-08	CIRCUIT BREAKER (10A), G2400R	1
37	351-45624-08	CIRCUIT BREAKER AC, G1300R	1
38	391-47802-01	AC VOLTMETER CPL.,G1300R	1
39	33K4995101	N/A	1
39	388-85003-01	AC RECEPTACLE (125V-20A),G6101R	1
40	363-45701-08	TERMINAL BOLT(RED), G2800R	1
41	363-45700-08	TERMINAL BOLT (BLK),G2800R	2
42	004-35030-60	SCREW & WASHER, G2410R .	4
43	004-35041-00	SCREW & WASHER, G2800R	2
44	002-17030-00	NUT, G2800R	2
45	056-30000-20	WIRE BAND, G2400R	3
46	353-54300-08	CONNECTOR(6P), G1300R	1
47	227-77002-00	LED LAMP ASSEMBLY, G1300R	1
48	013-10500-20	SCREW & WASHER ASS'Y, G1300R	4
50	350-60103-81	FUEL TANK CPL.,G1300R	1
51	227-66001-03	PLUG COVER, G1300R	1
52	350-65201-01	HANDLE, G1300R	1
53	002-18080-00	NUT, G1300R	2
54	003-20080-00	SPRING WASHER, G2800R	2
55	043-04300-41	FUEL TANK CAP COMPL., G1300R	1
56	064-13600-20	FUEL FILTER COMPL., G1300R	1
57	350-65501-03	BREATHER PIPE, G1300R	1
58	350-65401-13	HANDLE COVER, G1300R	1
59	004-31031-00	PAN HEAD SCREW, G1300R .	2
61	073-20026-31	CAUTION LABEL, G1300R	1
62	085-11100-00	RUBBER PIPE, G5711R,1M	1
63	056-11700-10	HOSE CLAMP, G5711R	2
64	053-30900-20	NUT (JOINT), G2400R	1
65	064-20049-02	FUEL STRAINER ASS'Y, G1300R	1
66	064-20024-10	LOCK NUT, G2400R	1



Parts Breakdown

G1300R

67	064-20019-10	CUP, G2400R	1
68	064-20002-30	PACKING, G2400R	1
69	064-20002-20	FILTER, G2400R	1
70	064-20003-30	O RING, G2400R	1
71	064-20002-40	BANJO BOLT, G2400R	1
72	064-20002-50	FIBER PACKING, G2400R	2
73	085-10600-00	RUBBER PIPE, G2410R,1M	1
74	052-10700-42	BANJO, G3500R	1
75	056-11100-20	HOSE CLAMP, G2800R	2
76	002-18080-00	NUT, G1300R	2
77	003-20080-00	SPRING WASHER, G2800R	2
78	226-10101-21	CRANKCASE COMPLETE, EW200R	1
79	227-14202-03	VALVE GUIDE, OVERSIZE, G2400R	2
80	044-02501-50	OIL SEAL 25X38X7MM, G2400R	1
81	060-02500-10	BALL BEARING, G2800R	1
82	031-00600-20	DOWEL PIN, G2800R	2
83	010-50802-50	STUD G2410R	2
84	010-50601-20	STUD, G2400R	2
85	227-11006-11	MAIN BEARING COVER CPL.,G1300R	1
86	044-02501-60	OIL SEAL 25X41.24X7MM, G2800R	1
87	060-02500-10	BALL BEARING, G2800R	1
88	227-45003-01	GOVERNOR GEAR COMPLETE, G2800R	1
89	205-41901-03	GOVERNOR SLEEVE, G2800R	1
90	227-17501-03	OIL SHELTER, SENSOR G2400R	1
91	004-35040-80	SCREW & WASHER ASSY, G2400R	2
92	226-13101-13	CYLINDER HEAD, G1300R	1
93	226-15001-11	GASKET COMPLETE, G1300R	1
93	281-15001-01	GASKET CPL., G1300R	1
94	227-16001-03	GASKET, BEARING COVER, G2400R	1
95	040-11400-30	PLUG, G2800R	2
96	021-11400-20	GASKET, G2800R	2
97	227-14301-01	TAPPET COVER, COMPLETE, G2400R	1
98	227-14401-01	BREATHER PLATE, COMPLETE, G2400R	1
99	227-16006-03	GASKET (TAPPET COVER), G2400R	1
99	282-16006-03	GASKET FOR TAPE COVER, G1300R	1
100	227-16007-03	GASKET, BREATHER PLATE, G2400R	1
100	282-16007-13	GASKET FOR BREATHER PLATE,G1300	1
101	085-10800-00	RUBBER PIPE, G2800R	1
102	011-00800-10	FLANGE BOLT, G2400R	8
103	013-00600-40	BOLT & WASHER ASSY, G2800R	8
104	011-00600-20	FLANGE BOLT, G6100R	2
105	226-27001-01	CRANKSHAFT CPL.,G1300R	1
106	226-22520-00	CONNECTING ROD ASS'Y, G1300R	1
107	226-23001-13	CONNECTING ROD BOLT, G1300R	2
108	226-23101-03	OIL SCRAPER, G1300R	1
109	214-23301-13	PISTON PIN, G2400R	1
109	2822330103	N/A	1
110	226-23411-03	PISTON (STD), G1300R	1
110	226-23412-03	PISTON (0.25MM), G1300R	1
110	226-23413-03	PISTON (0.50MM), G1300R	1
111	226-23511-07	PISTON RING SET (STD), G1300R	1
111	2262351117	N/A	1
111	226-23512-07	PISTON RING SET (0.25MM),G1300R	1
111	226-23513-07	PISTON RING SET(0.50MM),G1300R	1
112	056-51400-10	CLIP, G2400R .	2
113	023-02501-10	SPACER, (T=0.6), G2800R	1
113	023-02501-20	SPACER (T=0.8), G2800R	1
113	023-02501-30	SPACER, (T=1.0), G2800R	1
114	002-18140-00	NUT, 14MM, G2800R	1
115	003-20140-00	SPRING WASHER, 14MM, G2800R	1
116	032-30300-10	WOODRUFF KEY, 3X6MM, G2800R	1
117	226-31710-03	CAMSHAFT, G1300R	1
118	226-33301-03	TAPPET, G1300R	2
119	226-33401-03	INTAKE VALVE, G1300R	1
120	226-33501-13	EXHAUST VALVE, G1300R	1
121	227-33601-03	VALVE SPRING, G2400R	2
122	227-33701-03	SPRING RETAINER, G2400R	2



Parts Breakdown

G1300R

123	226-30302-11	MUFFLER CPL., G1300R	1
124	226-34206-11	MUFFLER COVER, G1300R	1
125	226-35201-01	GASKET COMPLETE, G1300R	1
126	226-32639-00	AIR CLEANER ASS'Y, G1300R	1
127	226-35010-11	CLEANER CASE, G1300R	1
128	227-36004-13	GASKET, G1300R	1
129	226-36003-03	ELEMENT RETAINER, G1300R	1
130	226-36004-03	ELEMENT, G1300R	1
131	004-35061-00	SCREW & WASHER, G1300R	1
132	227-32901-13	INSULATOR, G2400R	1
133	227-35901-03	INSULATOR GASKET, MAC6000	1
133	282-35901-03	GASKET, G1100	1
134	227-35904-03	INSULATOR GASKET 2, G2400R	1
135	227-36003-13	GASKET, AIR CLEANER G2400R	1
136	002-19080-00	NUT, G2400R	2
137	011-00600-10	FLANGE BOLT, G6100R	4
138	013-50600-10	BOLT & WASHER, G1300R	1
139	226-35408-01	ELEMENT COVER, G1300R	1
140	014-10600-30	SCREW, G1300R	1
141	003-10060-00	WASHER, G2410R	1
142	003-20060-00	SPRING WASHER, G2800R	1
143	011-00600-30	FLANGE BOLT, G2800R	1
144	002-38060-00	FLANGE NUT, G6101R	2
145	226-42301-11	GOVERNOR LEVER CPL., G1300R	1
146	227-42201-03	GOVERNOR SHAFT, G2800R	1
147	226-42501-13	GOVERNOR SPRING, G1300R	1
148	227-42701-01	GOVERNOR ROD, G2400R	1
149	227-42801-01	ROD SPRING, G2400R	1
149	227-42801-03	ROD SPRING, G1100	1
150	226-47101-11	CONTROL BRACKET, G1300R	1
151	226-45301-11	CONTROL LEVER, G1300R	1
152	226-45004-01	SPRING, G1300R	1
153	226-48001-11	BOLT, G1300R	1
154	226-43304-01	SPEED CONTROL, G1300R	1
155	226-48006-03	SPRING, G1300R	1
156	226-48003-01	BOLT, G1300R .	1
157	226-48004-01	SCREW, G1300R	1
158	226-48005-13	SPRING, G1300R .	1
159	003-13060-00	CLIP, G2800R	2
160	001-14062-50	BOLT & WASHER, G2800R	1
161	018-60600-20	NUT, G2800R .	1
162	226-43901-13	KNOB, G1300R	1
163	023-00801-60	SPACER, G1300R	1
164	226-51240-06	BLOWER HOUSING, G1300R .	1
166	226-50711-20	RECOIL STARTER ASS'Y, G1300R	1
166	281-50311-00	RECOIL STARTER, G1200R	1
166	2815031110	N/A	1
167	226-50716-08	SPIRAL SPRING, G1300R	1
168	226-50721-08	REEL, G1300R	1
168	2815032008	N/A	1
169	226-50726-08	RATCHET, G1300R	2
169	2815032508	N/A	1
170	226-50731-08	FRICITION SPRING, G1300R	1
170	2815033008	N/A	1
171	226-50753-08	CENTER SCREW, G1300R	1
171	2265075318	N/A	1
171	2815035108	N/A	1
172	226-50741-08	FRICITION PLATE, G1300R	1
172	2815034008	N/A	1
173	226-50710-18	STARTER ROPE, G1300R .	1
173	2815031008	N/A	1
174	226-50701-08	STARTER KNOB, G1300R	1
174	2815030008	N/A	1
174	2815030018	N/A	1
175	226-50745-08	STARTING PULLEY, G1300R	1
175	2815034508	N/A	1
177	2265280303	N/A	1



Parts Breakdown

G1300R

178	226-52602-03	CYLINDER BAFFLE, G1300R	1
179	011-00600-20	FLANGE BOLT, G6100R	2
180	011-00600-30	FLANGE BOLT, G2800R	1
181	011-00600-10	FLANGE BOLT, G6100R	7
182	226-62480-00	CARBURETOR ASS'Y, G1300R	1
183	214-62535-08	THROTTLE VALVE, G1300R	1
184	209-62351-08	SCREW ASS'Y, G5711R	1
185	237-62451-08	SCREW, G6101R	2
186	227-62527-08	CHOKE VALVE, G1300R	1
187	246-62420-08	PILOT JET (#40), G1300R	1
188	209-62352-08	SCREW, G1300R	1
189	209-62445-08	SPRING, G2800R	1
190	226-62502-08	NEEDLE VALVE ASS'Y, G1300R	1
191	214-62515-08	FLOAT PIN, G3510R	1
192	226-62506-08	FLOAT ASSEMBLY, G1200R	1
193	226-62530-08	SHAFT ASS'Y, THROTTLE, G2400R	1
194	226-62522-08	CHOKE LEVER, G1300R	1
195	226-62553-08	RING, G1300R	1
196	214-62540-08	FLOAT CHAMBER PACKING, G2400R	1
197	227-62558-08	FLOAT CHAMBER BODY, G1300R	1
198	227-62451-08	BOLT, G1300R .	1
199	214-62450-08	PACKING, G2400R	1
200	253-62401-08	MAIN JET (#73.8), G2800R	1
201	226-62456-08	MAIN NOZZLE, G1300R	1
202	227-62441-08	NOZZLE, G1300R	1
203	226-62701-08	CLIP, G1300R	1
204	226-62540-08	SPRING, G1300R	1
205	085-10400-00	RUBBER PIPE, G2400R	1
206	269-63601-03	OIL GAUGE, G2800R	1
207	021-31600-20	GASKET, G2800R	1
207	2776360108	N/A	1
207	X213160020	N/A	1
208	217-75002-03	PURSE LOCK (B), G1300R	1
209	226-70120-18	FLYWHEEL, G1300R	1
210	226-79430-41	IGNITION COIL CPL.,G1300R	1
210	226-79430-51	IGNITION COIL, G1300R	1
211	226-73110-01	WIRE 10 COMP. G1300R	1
212	065-01401-50	SPARK PLUG BR6HS, G2800R	1
213	065-50001-40	SPARK PLUG CAP, G5710R	1
214	065-90000-10	PLUG TERMINAL, G5710R	1
215	226-72702-01	STOP SWITCH COMP., G1300R	1
216	227-73107-01	WIRE 7 CPL.,G1300R	1
217	31101501KS	N/A	1
218	214-79006-01	CLAMP COMP., G2410R .	2
219	056-60002-50	CLAMP (ELEC STARTER),G2800R	1
220	003-10060-00	WASHER, G2410R	2
221	011-00601-21	FLANGE BOLT, G2400R	2
222	002-17040-00	NUT, G2800R	1
223	003-10040-00	WASHER, G6101R	1
229	226-36502-01	SPARK ARRESTER, G1300R	1
230	015-20500-20	TAPPING SCREW, G1300R	3
1,001	2269030400	ACCY TOOL KIT, G1300R	1