



BOSCH

Battery Vacuum Cleaner

GAS 18 V-LI | 3 601 JC6 180

Table of Content

Spare parts list.....	2
Illustration - Type.....	3

Battery Vacuum Cleaner | GAS 18 V-Li | 3 601 JC6 180

Spare parts list

Item	Part Number	Description	
2	1 619 PA5 183	DC motor	
22	1 619 PA5 185	Tapping Screw	
24	1 619 PA7 400	Filter Housing	
25	1 619 PA5 188	Filter	
26	1 619 PA5 187	Filter Cover	
27	1 619 PA5 190	Rubber Retaining Ring	
28	1 619 PA5 191	Protective Cover	
29	1 619 PA5 192	Screw	
30	1 619 PA5 193	Motor Cradle	
32	1 619 PA5 195	Electronics Module	
33	1 619 PA5 196	Carrying Loop	
34	1 619 PA5 197	Switch Button	
34/2	1 619 PB0 096	Sticker	
35	1 619 PA5 198	Button	
38	1 619 PA5 201	Dust Chamber	
651	1 619 PA5 202	floor nozzle	
651/2	1 619 PA7 502	Roller	
651/3	1 619 PA7 501	Shaft	
652	1 619 PA5 203	Holder	
653	1 619 PA5 204	Crevice Nozzle	
654	1 619 PA5 205	Suction Tube	
801	1 619 PA5 181	Housing Assembly	
815	1 619 PA5 184	Fan	
836	1 619 PA5 199	Switch Slide	
837	1 619 PA5 200	Rubber Disc	
852	1 607 A35 0JR	Battery Pack	GBA 18V 1.5Ah
852/1/22	2 601 115 537	Sticker	
853	2 607 225 439	Fast Charger	CN 220/10,8-18V, 1h
853	2 607 225 937	Charger	CN GAL 1880 CV 220V/14,4-18V
868	1 619 PA5 261	Brush	
869	1 619 PA5 263	Hook	
870	1 619 PA5 354	Screw	

Illustration - Type - E

