



BOSCH

Drill

GBM 600 | 3 601 AA4 580

Table of Content

Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description
1	1 619 PA4 164	Housing Section
2	1 619 PA4 180	Field 220-240V
4	1 619 PA4 597	Switch
5	1 619 PA4 598	Power supply cord
6	1 619 PA4 599	Grommet
7	1 619 PA4 600	Cable Clip
12	1 619 PA4 604	Suppression Filter
16	1 619 PA4 606	Brush Holder
22	1 619 PA4 607	Chuck
23	1 619 PA4 608	Chuck Wrench
24	1 619 PA4 609	Drilling Spindle
25	1 619 PA4 610	Ball Bearing
26	1 619 PA4 611	Spacer Ring
27	1 619 PA4 612	Cylindrical Gear
28	1 619 PA4 613	Bearing Bracket
29	1 619 PA4 614	Pin
30	1 619 PA4 615	Inductor
31	1 619 PA4 616	Lever
32	1 619 PA4 617	Tapping Screw
33	1 619 PA4 618	Tapping Screw
803	1 619 PA5 010	Armature set 220-240V
810	1 619 PA4 619	Carbon-Brush Set

Illustration - Type - E

