



**BOSCH**

# Cutoff saw

GCO 14-2 | 0 601 B11 043

---

## Table of Content

Spare parts list.....	2
Illustration - Type.....	6

## Spare parts list

Item	Part Number	Description
1	1 609 203 E42	Screw
2	1 609 203 E43	Spring Washer
3	1 609 203 E44	Plain Washer
4	1 609 203 E45	Housing Cover
5	1 609 203 E46	Cover
6	1 609 203 E47	Bearing cover
7	1 609 203 E48	Nameplate
8	1 609 902 179	Screw
10	1 609 902 414	Motor Housing
16	1 609 203 E57	Plain Washer
17	1 609 203 E58	Screw
18	1 609 902 404	Stator
19	1 609 203 E60	Ball Bearing
20	1 609 203 E61	Plain Washer
21	1 609 203 E62	Spring Washer
22	1 609 203 E63	Screw
23	1 609 203 E64	Air-Deflector Ring
24	1 609 902 411	Rotor
25	1 609 203 E66	Carbon Brush Holder
26	1 609 902 320	Carbon-Brush Set
27	1 609 203 E68	Brush-Cover
28	1 609 203 E69	Toothed lock washer
29	1 609 203 E70	Screw
32	1 609 203 E73	Ball Bearing
33	1 609 203 E74	Gear Housing
34	1 609 203 E75	Locking Pin
35	1 609 203 E76	Handle
36	1 609 203 E77	Spring
37	1 609 203 E78	Plain bearing
38	1 609 203 E79	Spring retaining ring
39	1 609 902 181	Toothed Gear
40	1 609 203 E81	Spacer Tube
41	1 609 203 E82	Spring retaining ring
42	1 609 203 E83	Ball Bearing
43	1 609 203 E84	Bearing cover

## Spare parts list

Item	Part Number	Description
44	1 609 203 E85	Parallel Key
45	1 609 902 183	Grinding Spindle
46	1 609 203 E87	Clamping Flange
47	1 609 203 E88	Sleeve
49	1 609 902 193	O-Ring
50	1 609 203 E91	Plain Washer
51	1 609 203 E92	Hex Screw
67	1 609 203 F07	Protective Cover
68	1 609 203 F08	Hex Nut
69	1 609 203 F09	Plain Washer
70	1 609 203 F10	Reference Plate
71	1 609 203 F11	Cover
72	1 609 203 F12	Flap Guard
73	1 609 203 F13	Screw
91	1 609 203 F31	On-Off Switch
92	1 609 203 F32	Inductor
93	1 609 203 F33	Tape
94	1 609 203 F34	Screw
95	1 609 203 F35	Handle
96	1 609 203 F36	Screw
97	1 609 203 F37	Fastening Clamp
98	1 609 203 F38	Power supply cord
99	1 609 203 F39	Cord guard
100	1 609 203 F40	Handle
106	1 609 203 G33	Rubber Plug
107	1 609 203 G34	Shrinkable Tube
108	1 609 203 G35	connecting terminal
109	1 609 203 G36	Protection Sleeve
110	1 609 203 G37	connecting terminal
111	1 609 203 G38	Rubber Plug
112	1 609 203 G39	Screw
113	1 609 203 G40	Terminal-Parts Set
116	1 609 902 326	Suppression Filter
11	1 609 203 E52	Locking Lever
12	1 609 203 E53	Guiding bolt

## Spare parts list

Item	Part Number	Description
13	1 609 203 E54	Taper Pin
14	1 609 203 E55	Torsion Spring
30	1 609 203 E71	O-Ring 4,8x1,8 MM
31	1 609 203 E72	Locking Bolt
52	1 609 203 E93	Locking Bolt
53	1 609 902 419	Base Plate
54	1 609 203 E95	Spring Holder
55	1 609 203 E96	Hex Screw
56	1 609 203 E97	Hex Nut
57	1 609 203 E98	Holding Fixture
58	1 609 203 E99	Split Pin
59	1 609 203 F00	Plain Washer
60	1 609 203 F01	Clamp Screw
61	1 609 203 F02	Handle
62	1 609 203 F03	Straight Pin
63	1 609 203 F04	Bolt
64	1 609 203 F05	Clamping jaws
65	1 609 203 F06	Spring retaining ring
66	1 609 203 F43	Stop Bracket
75	1 609 203 F15	Hex Nut
76	1 609 203 F16	Bumper
77	1 609 203 F17	Plain Washer
78	1 609 203 F18	Spring Washer
79	1 609 203 F19	Screw
80	1 609 203 F20	Spacer Bolt
81	1 609 902 187	Rubber Buffer
82	1 609 902 188	Screw
83	1 609 203 F23	Screw
84	1 609 203 F24	Spring Washer
85	1 609 203 F25	Plain Washer
86	1 609 203 F26	Supporting Block
87	1 609 203 F27	Catch Lever
88	1 609 203 F28	Bolt
89	1 609 203 F29	Swing-Plate
101	1 609 203 F41	Handle

Spare parts list

Item	Part Number	Description
115	1 609 902 294	Spacer

Illustration - Type - E

0 601 B11 004  
 Stand 08-99  
 Issue 12-11-13

Fig./Abb. 1





