



BOSCH

Delta Sander

GEX 270 A | 0 601 37A 094

Table of Content


Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description
1	2 605 105 021	Housing Section
2	2 609 005 423	Field
4	2 607 200 526	Switch
5	2 604 460 245	Power supply cord CN 220V 2,65m 2 x 0,75mm H05 VV-F
6	2 609 002 019	Grommet
7	2 603 490 017	Torx Oval-Head Screw 3x10
9	2 601 116 040	Manufacturer's nameplate
10	2 604 337 088	Brush Plate
19	2 603 490 022	Screw 4x16
21	2 608 601 161	Tool Holding Fixture
22	2 916 011 895	Plain Washer DIN 9021-B 8,4-ST
23	2 600 206 021	Friction Ring
24	2 911 061 232	Hex Screw M8x10-8.8-A M31A
25	2 604 448 113	Connecting Cable L=180MM BLUE
26	3 604 440 527	Connecting Cable L=63 MM WHITE
28	2 608 601 172	Backing Pad
29	2 603 413 035	Oval-Head Screw M4x8
40	2 609 000 549	Rubber Buffer
41	2 605 411 121	Dust container 1 PIECE
803	2 604 010 985	Armature 230-240V
808	2 601 116 627	Nameplate
811	2 604 321 925	Carbon-Brush Set

Illustration - Type - E

0 601 37A 004
 Stand Issue } 02-06-12 **Fig./Abb. 1**



Änderungen vorbehalten
 Modifications reserved
 Modifications reserves
 Salvo modificaciones