



BOSCH

Circular saw

GKT13-225 BT | 3 601 F75 010

Table of Content

Spare parts list.....	2
Illustration - Type.....	4

Spare parts list

Item	Part Number	Description	Illustration
4	1 600 A01 61Z	On-Off Switch	1
5	1 604 460 777	Power supply cord	1
6	2 600 707 079	Grommet	1
9	1 601 11C 2PU	Manufacturer's nameplate	1
16	2 604 449 061	Brush Holder	1
21	1 600 A01 L72	Depth-Gauge	1
22	1 605 806 5WK	Gear Housing	1
23	2 605 510 315	Protective Cover	1
25	2 605 510 316	Protective Cover	1
26	2 605 133 034	Handle	1
27	2 605 133 036	Handle	1
28	2 605 500 210	Switch Actuator	1
29	2 601 322 048	Carrier	1
30	2 601 322 049	Carrier	1
31	2 602 051 003	Locking Lever	1
32	2 603 181 011	Lock bolt	1
33	2 601 099 269	Locking Slide	1
34	2 602 026 178	Thumbwheel	1
35	2 601 330 007	Catch Lever	1
36	2 605 730 065	Suction Socket	1
38	2 605 105 184	Housing Cover	1
39	2 600 290 064	Air-Deflector Ring	1
40	2 600 406 037	Spring Guide	1
41	2 601 099 270	Pusher	1
47	2 601 990 049	Brake Lever	1
48	2 601 098 504	Catch Lever	1
49	2 605 700 250	Clamping-Flange	1
50	2 600 114 086	Clamping-Flange	1
53	2 603 100 075	Bearing Pin	1
54	2 603 402 009	Set screw	1
57	2 603 415 212	Torx Oval-Head Screw	1
58	2 603 415 213	Torx Oval-Head Screw	1
59	2 603 410 064	Socket head cap screw	1
60	2 603 415 214	Torx Oval-Head Screw	1
61	2 603 415 215	Torx Oval-Head Screw	1

Spare parts list

Item	Part Number	Description	Illustration
62	2 603 415 216	Torx Oval-Head Screw	1
63	1 603 435 08U	Torx Oval-Head Screw	1
64	2 603 415 218	Torx Oval-Head Screw	1
65	2 603 415 219	Torx Oval-Head Screw	1
67	2 600 100 242	Washer	1
68	2 600 118 022	Spring retaining ring	1
69	2 600 100 243	Locking Washer	1
70	2 600 100 244	Locking Washer	1
71	2 600 101 516	Thrust Bearing Disc	1
72	2 600 100 245	Washer	1
73	2 600 905 118	Ball Bearing	1
74	2 600 905 119	Ball Bearing	1
75	2 600 210 053	O-Ring	1
76	2 600 210 054	O-Ring	1
77	2 600 210 055	O-Ring	1
79	2 600 200 054	Disc Spring	1
80	2 604 618 005	Compression Spring	1
81	2 604 650 006	Extension Spring	1
82	2 604 618 006	Compression Spring	1
83	2 604 618 007	Compression Spring	1
84	2 600 030 026	Thrust Member	1
85	2 600 026 007	Brake Lining	1
86	1 600 A01 623	Cable Clip	1
87	2 607 230 145	Speed governor	1
89	2 610 364 015	Hexagon Socket Screw Key 5 MM	1
522	1 600 A01 97B	Warning Label	1
523	1 600 A01 622	Warning Label	1
801	2 605 108 922	Motor Housing	1
802	2 604 220 754	Pole Shoe 110-120V	1
803	2 604 011 938	Armature 110-120V	1
808	1 601 11A 6MN	Nameplate	1
810	2 604 321 104	Carbon-Brush Set	1
824	2 601 016 907	Base Plate	1
851	2 603 124 907	Drive Shaft	1
878	2 603 434 004	Set of screws	1

Illustration - Type - E

