



## Parts List for GL300-B3 Type 1

Item Number	Part Number	Description	Qty Required
1	5140018-69	SPOOL CAP	1
2	5140018-70	SPOOL HOLDER	1
3	5140018-71	SPOOL	1
4	5140018-72	SPRING	1
5	5140018-73	SPOOL HOUSING	1
6	5140018-74	GUARD	1
7	5140018-67	MOTOR	1
8	5140018-75	HOUSING,LH	1
9	5140018-76	STOP	1
10	5140018-77	TUBE	1
11	5140018-78	KNOB, ADJ.	1
12	5140018-79	JOINT	1
13	5140018-80	JOINT	1
14	5140018-81	SLEEVE	1
15	5140018-82	TERMINAL	1
16	5140018-83	LOCK PIN	1
17	5140018-84	PAD	1
18	5140018-85	LOCK BUTTON	1
19	5140018-86	CONNECTOR ASSY	1
20	5140018-87	SWITCH	1
21	5140018-88	HOUSING,LEFT	1
22	5140018-89	GEL PAD	1
23	5140018-90	CAPACITOR	1
24	5140018-91	CORD CLAMP	1
25	5140018-92	CORD PROTECTOR	1
26	5140018-93	HOUSING, RH	1
27	5140018-68	CORD	1

## Parts List for GL300-B3 Type 1

Item Number	Part Number	Description	Qty Required
28	5140018-94	ACTUATOR	1
29	5140018-95	NUT	1
30	5140018-96	HOUSING,RIGHT	1