



BOSCH

Multipurpose tool

GOP 18V-34 | 3 601 HG2 010

Table of Content

Spare parts list.....	2
Illustration - Type.....	4

Spare parts list			
Item	Part Number	Description	Illustration
1	1 619 PB9 829	Motor Housing	1
2	1 619 PB9 376	Field assembly	1
3	1 619 PB9 377	Armature	1
9	1 619 PB9 804	Manufacturer's nameplate	1
13	1 619 PB9 830	groove ball bearing	1
14	1 619 PB9 831	groove ball bearing	1
22	1 619 PB9 832	Spring	1
23	1 619 PB9 833	Block	1
24	1 619 PB9 834	Motor Housing	1
25	1 619 PB9 835	Clamping bracket	1
26	1 619 PB9 836	Spacer Ring	1
27	1 619 PB9 837	Gasket	1
28	1 619 PB9 838	Eccentric Shaft	1
29	1 619 PB9 839	Counterweight	1
30	1 619 PB9 840	Plain Washer	1
31	1 619 PB9 841	Ball Bearing	1
32	1 619 PB9 842	Backup ring	1
33	1 619 PB9 843	Bearing Flange	1
34	1 619 PB9 844	O-Ring	1
36	1 619 PB9 846	Damping Ring	1
37	1 619 PB9 847	Switch Slide	1
38	1 619 PB9 848	Cover	1
39	1 619 PB9 849	Lever	1
40	1 619 PB9 850	Torsion Spring	1
41	1 619 PB9 851	Contact Screw	1
42	1 619 PB9 852	Insulating Plate	1
43	1 619 PB9 853	Block	1
44	1 619 PB9 854	Torsion Spring	1
49	1 619 PB9 859	Damping Ring	1
64	1 619 PB9 874	Screw	1
65	1 619 PB9 898	O-Ring	1
66	1 619 PB9 875	Screw	1
67	1 619 PB9 876	Seal	1
68	1 619 PB9 877	Screw	1
69	1 619 PB9 878	Wire Retainer	1

Spare parts list

Item	Part Number	Description	Illustration
70	1 619 PB9 879	Detent Roller	1
71	1 619 PB9 880	Spacer	1
72	1 619 PB9 881	Screw	1
74	1 619 PC1 155	Warning Label	1
75	1 619 PC0 610	Sticker	1
624	1 619 PB9 882	Gear Head	1
625	1 619 PB6 095	Electronics Module	1
808	1 619 PC1 153	Nameplate	1

Illustration - Type - E

