



BOSCH

Laser Level

GRL 160DHV | 3 601 K61 210

Table of Content

Spare parts list.....	2
Illustration - Type.....	3

Spare parts list

Item	Part Number	Description	Illustration	Price	Quantity	Price Group
1	1 618 C01 487	Cable	1	-	1	
2	1 618 C00 588	Base	1	-	2	
3	1 618 C00 875	Plug	1	-	1	
4	1 618 C00 772	Battery Cover	1	-	1	
5	1 618 C00 773	Motherboard	1	-	1	
6	1 618 C00 624	Cradle	1	-	1	
7	1 618 C00 780	Housing	1	-	1	
8	1 618 C00 666	Cap-Handle	1	-	1	
9	1 618 C00 781	Cover Frame	1	-	1	
10	1 618 C00 791	Housing	1	-	1	
11	1 618 C00 729	Stud	1	-	1	
12	1 618 C00 733	Plug	1	-	1	
13	1 618 C00 792	Cap	1	-	1	
14	1 618 C00 793	Cap	1	-	1	
15	1 618 C00 794	Switching Mechanism	1	-	1	
650/1	1 618 C00 822	Battery Cover	1	-	1	
652/1	1 618 C00 884	Screw	1	-	3	
652/2	1 618 C00 886	Screw	1	-	1	
653	1 618 C00 477	Hexagon Socket Wrench	1	-	1	

* Prices shown are suggested retail prices

Illustration - Type - E

3601 K61 210
Issue | 09-03
Stand | 09-04-23

Fig./Abb. 1

