



**BOSCH**

# Laser Level

GRL 400 H | 3 601 K61 810

---

## Table of Content

Spare parts list.....	2
Illustration - Type.....	4

**Spare parts list**

<b>Item</b>	<b>Part Number</b>	<b>Description</b>	<b>Illustration</b>
1/1/1	1 605 108 2MS	Motor Housing	1
1/1/10	2 610 A13 399	Limit Switch	1
1/1/2	1 600 A01 NM3	Leveling element	1
1/1/3	2 610 A13 397	Limit Switch	1
1/1/4	2 610 A12 269	Special Washer	1
1/1/5	2 610 A12 272	Hex Socket Head Cap Screw	1
1/1/6	2 610 A12 284	Hex Socket Head Cap Screw	1
1/1/7	2 610 A12 359	Flexible Pcb	1
1/1/8	2 610 A12 301	Tapping Screw	1
1/2	2 610 A12 298	lens mount	1
1/3	2 610 A13 366	Rotation Unit	1
1/4	2 610 A13 908	Assembly	1
1/5	2 610 A12 224	ball sleeve	1
1/6	2 610 A12 362	Hex Socket Head Cap Screw	1
2	2 610 A14 450	Housing	1
3	2 610 A12 957	Housing	1
4	2 610 A12 464	Handle	1
5	2 610 A12 309	Handle	1
6	2 610 A12 327	Battery box assembly	1
7	2 610 A13 906	Cage	1
8	2 610 A12 310	Threaded Bolt	1
9	2 610 A12 348	Hex Socket Head Cap Screw	1
10	2 610 A12 459	Hex Socket Head Cap Screw	1
11	2 610 A12 460	Hex Socket Head Cap Screw	1
12	2 610 A14 016	Nameplate	1
14	2 610 A13 405	Keyboard	1
15	2 610 A06 622	Window	1
16	2 610 A13 364	Rubber Gasket	1
17	2 610 A13 365	Rubber Gasket	1
18	2 610 A12 283	Extension Spring	1
19	2 610 A13 065	Extension Spring	1
24	2 610 A13 249	Motor-gearbox assembly	1
25	2 610 A12 302	Motor Plate	1
27	2 610 A12 275	Hex Socket Head Cap Screw	1
801/1/1	2 610 A14 673	Motor Housing	1

**Spare parts list**

<b>Item</b>	<b>Part Number</b>	<b>Description</b>	<b>Illustration</b>
801/1/2	1 600 A02 0P8	Leveling element	1
801/4	1 600 A01 R86	Assembly	1
802	1 600 A01 R89	Housing	1
824	1 600 A01 R7V	Motor-gearbox assembly	1

Illustration - Type - E

3 601 K61 810  
Issue  
Stand } 20-06-30 **Fig./Abb. 1**

