



Model GRM02 Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	SE00000521	SCREW PTB 3X8(ZK) 29S16308001	4	PC.
002	SE00000903	PCB A ASS'Y	1	PC.
003	SE00000521	SCREW PTB 3X8(ZK) 29S16308001	7	PC.
004	SE00000905	PCB C ASS'Y	1	PC.
005	SE00000521	SCREW PTB 3X8(ZK) 29S16308001	2	PC.
006	SE00000848	PCB P ASS'Y (BAR ANT)	1	PC.
007	SE09090011	SCREW 1.7	5	PC.
008	SE00000907	POWER KEY HOLDER	1	PC.
009	SE00000908	POWER KEY	1	PC.
010	SE09090011	SCREW 1.7	5	PC.
011	SE00000909	PRESET KEY HOLDER	1	PC.
012	SE00000910	PRESET KEY	1	PC.
013	SE00000521	SCREW PTB 3X8(ZK) 29S16308001	2	PC.
014	SE00000911	KNOB LENS HOLDER	1	PC.
015	SE00000912	FRONT CABINET ASS'Y MR002G	1	PC.
	D10	INC. 7-12,19,20		
016	SE09064161	SCREW M4X16	4	PC.
017	SE00000854	SCREW PTF 3X6(ZK)	2	PC.
018	SE00000521	SCREW PTB 3X8(ZK) 29S16308001	7	PC.
019	SE00000855	RUBBER KEY	1	PC.
020	SE00000856	FRONT PACKING	1	PC.
021	SE00000913	FRONT BUMPER ASS'Y	1	PC.
022	SE00000916	JACK RUBBER COVER	1	PC.
023	SE00000860	JACK COVER	1	PC.
024	SE00000754	EN/SW WASHER	1	PC.
025	SE00000755	EN/SW NUT	1	PC.
026	SE21B1110A	ROTARY KNOB RING	1	PC.
027	SE00000861	ROTARY KNOB(BLK)	1	PC.
028	SE00000862	FRONT BAR	2	PC.
029	SE00000709	SCREW PTHE 6X33(CR)	4	PC.
030	SE09176166	HEX SCREW M6X16	1	PC.
031	SE00000863	BATTERY BUMPER-L	1	PC.
032	SE09176166	HEX SCREW M6X16	1	PC.
033	SE00000864	BATTERY BUMPER-R	1	PC.
034	SE09176166	HEX SCREW M6X16	1	PC.
035	SE00000865	REAR BUMPER-L	1	PC.
036	SE09176166	HEX SCREW M6X16	1	PC.
037	SE00000866	REAR BUMPER-R	1	PC.
038	SE00000917	LOCKER COVER	1	PC.
039	SE00000868	PIN D2X84	1	PC.
040	SE00000536	LOCKER HINGE 3300B30000010	1	PC.
041	SE00000920	BATTERY COVER ASS'Y	1	PC.
	D10	INC. 38-40,42,43		
042	SE00000539	PIN D2X77 2100B300200	1	PC.
043	SE00000872	XGT PLATE	1	PC.
044	SE00000521	SCREW PTB 3X8(ZK) 29S16308001	4	PC.
045	SE00000873	BATTERY COVER PACKING	1	PC.
046	SE0307PC5Z	BACK UP BATTERY COVER	1	PC.
047	SE021E9030	+/- BATTERY CONTACT ASS'Y	1	PC.

048	SE00000467	BATTERY CONTACT (-)2100PL00200	1 PC.
049	SE00000466	BATTERY CONTACT(+) 2100RA00700	1 PC.
050	SE9076146A	HEX SCREW M6X14	4 PC.
051	SE024J9070	PACKING	4 PC.
052	SE00000874	SPEAKER PANEL ASS'Y	1 PC.
053	SE09090023	SCREW M4X12	4 PC.
054	SE00000875	RIGHT SPEAKER ASS'Y	1 PC.
055	SE00000876	SPEAKER PACKING	1 PC.
056	SE00000877	BATTERY COVER FIXER PIN	1 PC.
057	SE00000404	SCREW PTHE 3X14(CR)	1 PC.
058	SE00000878	DC JACK COVER	1 PC.
059	SE00000176	SCREW PTHE6X20(CR)	1 PC.
060	SE00000715	SCREW PTHE 6X17(CR)	1 PC.
061	SE00000879	HANDLE L	1 PC.
062	SE00000881	HANDLE BAR	1 PC.
063	SE00000184	SPRING	2 PC.
064	SE09994007	STEEL BALL	2 PC.
065	SE09994007	STEEL BALL	2 PC.
066	SE00000184	SPRING	2 PC.
067	SE00000883	HANDLE R ANT(B)	1 PC.
068	SE00000176	SCREW PTHE6X20(CR)	1 PC.
069	SE00000716	SCREW PTHE 7X16(CR)	1 PC.
070	SE00000717	SCREW PTHE 10.8X4.5(CR)	1 PC.
071	SE00000926	REAR CABINET ASS'Y	1 PC.
	D10	INC. 47,48,49,79	
072	SE00000445	SCREW PTB 3X45(NI)	2 PC.
073	SE00000888	HANDLE SUS-PLATE(R)	1 PC.
074	SE00000889	HANDLE SUS-PLATE(L)	1 PC.
075	SE00000929	DC JACK HOLDER	1 PC.
076	SE00000930	PCB F ASS'Y (DC JACK)	1 PC.
077	SE09090011	SCREW 1.7	2 PC.
078	SE00000892	SPEAKER HOLDER	1 PC.
079	SE00000587	LEAD WIRE W/CONNECTOR 170MM	1 PC.
080	SE00000892	SPEAKER HOLDER	1 PC.
081	SE00000876	SPEAKER PACKING	1 PC.
082	SE00000893	LEFT SPEAKER ASS'Y	1 PC.
083	SE09090023	SCREW M4X12	4 PC.
084	SE00000874	SPEAKER PANEL ASS'Y	1 PC.
085	SE024J9070	PACKING	4 PC.
086	SE9076146A	HEX SCREW M6X14	4 PC.
087	SE00000894	XGT TERMINAL(36V) ASS'Y	1 PC.
088	SE00000193	SCREW 3X10	5 PC.
089	SE00000895	CXT TERMINAL 10.8v-A-3PIN ASS'	1 PC.
090	SE00000521	SCREW PTB 3X8(ZK) 29S16308001	2 PC.
091	SE00000896	LXT TERMINAL(18V) ASS'Y	1 PC.
092	SE00000521	SCREW PTB 3X8(ZK) 29S16308001	2 PC.
093	SE00000897	PCB D+M ASS'Y (BATT._DET)	1 PC.
094	SE00000521	SCREW PTB 3X8(ZK) 29S16308001	4 PC.
095	SE00000898	W/TIES 150mm	1 PC.
096	SE00000195	W/TIES 100MM	1 PC.
097	SE00000899	REAR CABINET PACKING	1 PC.
A01	SE00000681	AC ADAPTER (UL)	1 PC.