




Model GRM05 Parts List

Item#	Part#	Description	Q'ty
001	SE00001259	PCB C ASSY	1
002	SE00000521	SCREW PTB 3X8(ZK) 29S16308001	2
003	SE00001260	PCB E ASSY(L)	1
004	SE00001261	PCB E ASSY(R)	1
005	SE00001262	LED RUBBER	2
006	SE00000521	SCREW PTB 3X8(ZK) 29S16308001	6
007	SE00001263	DISPLAY PLATE	1
008	SE00001264	RUBBER KEY	1
009	SE00001265	FRONT CABINET ASSY	1
	D10	INC. 7,8	
010	SE00000530	SCREW PTHE 6X37(CR) 29S1793701	4
011	SE00001266	SPEAKER PACKING	1
012	SE00001267	SPEAKER ASSY	1
013	SE00000557	SCREW PTPW 3X10(ZK) 29S1531000	4
014	SE00001268	FRONT LENS	1
015	SE00001269	SPEAKER GRILL ASSY	1
016	SE00001270	LOCKER COVER	1
017	SE00001271	PIN D2X108	1
018	SE00001272	PIN D2X99	1
019	SE00001273	LOCKER HINGE	1
020	SE00001274	BATTERY COVER ASSY	1
021	SE00001275	PIN D4X54	2
022	SE00001276	PIN HOLDER	1
023	SE00000521	SCREW PTB 3X8(ZK) 29S16308001	2
024	SE00001277	BATTERY PACKING	1
025	SE09176166	HEX SCREW M6X16	1
026	SE00001278	HANDLE ASSY	1
027	SE09176166	HEX SCREW M6X16	1
028	SE00000451	SCREW PTB 3X12 ZK 29S16312001	2
029	SE00001279	REAR BUMPER	1
030	SE00000445	SCREW PTB 3X45(NI)	2
031	SE00001280	REAR CABINET ASSY	1
	D10	INC. 41	
032	SE00001281	HANDLE SUS PLATE	1
033	SE00001282	PASSIVE GRILL	1
034	SE00001281	HANDLE SUS PLATE	1
035	SE00001282	PASSIVE GRILL	1
036	SE00001283	PCB D ASSY	1
037	SE00000521	SCREW PTB 3X8(ZK) 29S16308001	2
038	SE00000451	SCREW PTB 3X12 ZK 29S16312001	1
039	SE00000521	SCREW PTB 3X8(ZK) 29S16308001	2
040	SE00000451	SCREW PTB 3X12 ZK 29S16312001	1
041	SE00001284	REAR PACKING	1
042	SE00001285	REAR BUMPER L	1
043	SE00001286	TERMINAL ASSY	1
044	SE00000521	SCREW PTB 3X8(ZK) 29S16308001	6
045	SE00000521	SCREW PTB 3X8(ZK) 29S16308001	3
046	SE00001287	JACK COVER ASSY	1
047	SE00001288	PCB B ASSY	1
048	SE00001289	REAR BUMPER R ASSY	1
	D10	INC. 49	

049	SE00001290	JACK RUBBER COVER	1
050	SE00001292	PCB A ASSY	1
051	SE00000521	SCREW PTB 3X8(ZK) 29S16308001	4
052	SE00000195	W/TIES 100MM	1
A01	SE00001252	AC ADAPTER UL	1