



Parts List for GS500K Type 1

Item Number	Part Number	Description	Qty Required
1	330013-02	SCREW,PLASTIC	8
4	243135-00	BLADE	1
5	91247-00	GEAR	1
6	086753-00	WASHER	1
7	680945-00	SCREW	2
10	243150-01SV	BATTERY-3.6V	1
12	000000-00	No Longer Available	2
13	90522204	CHARGER	1
16	91246-00	GEAR & PINION	1
18	33314-00	CONNECTOR	4
20	000000-00	No Longer Available	1
24	464224-02	SWITCH	1
25	243755-03	LOCK-OFF BUTTON	1
26	380657-00	LABEL,WARNING	1
27	244496-00	NAMEPLATE	1
800	93488-00	GREASE	1
862	244534-00	STORAGE BAG	1