



**BOSCH**

# Percussion Drill

GSB 20-2 | 0 601 184 243

---

## Table of Content

Spare parts list.....	2
Illustration - Type.....	4

**Spare parts list**

Item	Part Number	Description
1	2 605 104 653	Motor Housing BLUE
2	1 604 220 254	Field 220-240V
3	1 619 P00 491	Armature 220-240V
3/50	2 606 610 029	Fan
4	2 607 200 365	On-Off Switch
5	1 619 P00 435	Power supply cord H05 RN-F CN 2,65m 2 x 1,00mm
6	1 619 P14 639	Grommet Ø 7mm
6	2 600 707 059	Grommet Ø6,9 MM
6	2 600 707 060	Grommet Ø11,6-Ø12,5x84 MM
7	2 601 035 001	Cable Clip
9	2 601 117 013	Manufacturer's nameplate
13	1 900 905 018	Ball Bearing 7x22x7
14	1 619 P02 417	groove ball bearing
18	2 603 410 001	Socket head cap screw M3x6,5-4.8
19	1 619 P00 029	Screw
20	2 601 117 006	Reference Plate SHADOW SIDE
24	2 606 135 086	Drilling Spindle SW 14
25	2 605 806 422	Gear Housing BLUE
26	2 604 616 006	Compression Spring
27	2 600 301 031	Sintered-Metal Bushing 14,7-0,15
28	2 916 650 008	Spring retaining ring DIN 471 17x1 MM
29	2 600 101 047	Shim 0,3 MM
30	2 602 300 034	Flat Key
31	2 600 101 084	Retaining Washer
32	2 600 101 515	Shim 1,0 MM
33	2 606 317 083	Cylindrical Gear
34	2 606 317 082	Cylindrical Gear
35	2 601 098 031	Guiding Plate
36	2 600 190 070	Catch Disk
37	2 600 190 071	Catch Disk
38	2 603 410 048	Thread-forming tap. Screw M4x8
39	2 600 000 012	Shim washer 0,2 MM
39	2 600 000 014	Shim washer 0,5 MM
40	1 903 230 010	Ball DIN 5401-5,5MM-III-ST

**Spare parts list**

<b>Item</b>	<b>Part Number</b>	<b>Description</b>		
41	2 602 026 072	Rotary Knob	BLACK	
42	2 917 780 101	Slotted Spring Pin	DIN 7346 4x24	
44	2 601 328 033	Cover Disc		
45	1 619 P00 220	Torx Oval-Head Screw	3x10	
46	2 605 132 051	Housing Cover	BLUE	
47	2 604 337 003	Brush Holder		
49	2 600 150 004	Shim		
50	2 600 101 027	Shim washer	0,3 MM	
50	2 600 101 665	Shim washer	0,2 MM	
50	2 600 101 667	Shim washer	0,5 MM	
51	2 604 448 005	Cable	L=130 MM	WHITE
53	2 604 448 133	Connecting Cable	L=96MM	WHITE
56	2 600 914 010	Needle-Roller Bearing	Ø6 MM	
57	2 600 400 027	Bearing Sleeve		
61	2 600 100 607	Shim	0,3 MM	
62	2 600 500 002	Cupped Washer		
63	2 603 435 070	Headless Screw		
64	2 603 435 071	Headless Screw	65 MM	
66	2 602 033 011	Adjusting Slide		
68	2 600 100 618	Shim washer		
69	2 602 026 038	Rotary Knob	BLACK	
71	2 600 590 006	Ratchet Cap		
75	1 619 P00 031	Torx Oval-Head Screw		
76	1 619 P00 030	Torx Oval-Head Screw		
80	2 601 073 012	Gasket		
780	1 608 571 069	Chuck	Ø1,5-13 MM, 1/2"	
780/7	2 607 950 007	Chuck Wrench	SG2	
808	2 601 119 816	Nameplate		
810	2 604 321 905	Carbon-Brush Set		
843	2 605 700 941	Intermediate Flange		
859	2 606 309 931	Toothed Shaft	Z= 10/29/22	
867	2 916 080 007	Locking Washer	DIN 6799-4-FSt	
870	2 607 010 226	Parts Set		

Illustration - Type - E

