



BOSCH

Portable Metal Shears

GSC 18V-16 | 3 601 J26 280

Table of Content

Spare parts list.....	2
Illustration - Type.....	4

Portable Metal Shears | GSC 18V-16 | 3 601 J26 280

Spare parts list

Item	Part Number	Description		
1	1 605 108 282	Housing Section	BLUE	
9	3 601 110 616	Manufacturer's nameplate	GSC 18V-16	
18	1 602 025 071	Switch Button		
20	1 602 319 023	Adjusting Slide		
46	1 609 280 477	Compression Spring		
51	1 607 233 340	Electronics Module		
51/200	1 609 280 478	Contact retainer		
52	2 607 202 071	On-Off Switch		
91	1 603 435 071	Thread-forming tap. Screw		
97	3 605 700 213	Intermediate Flange		
98	3 600 200 041	Felt Washer		
102/17/21	1 600 102 029	Washer	1,0 MM	THICK
102/17/22	1 606 337 004	Ring Gear		
102/17/23	1 606 337 003	Planet Gear		
102/17/27	3 600 102 049	Shim ring		
102/17/28	3 602 311 052	U-Sheet		
102/17/29	3 600 905 158	Track-Supporting Roller		
102/17/30	1 600 900 038	Ball Bearing	626 DIN 625	
102/17/31	1 605 190 266	Gear Housing		
102/17/32	3 602 317 042	Tappet		
102/17/33	2 910 401 118	Hex Socket Head Cap Screw	M4x8-12.9 DIN 912-	
102/17/34	3 608 635 009	Knife		
102/17/35	3 602 311 047	Plain Washer	0,2 mm	
102/17/36	3 606 455 042	Cutting Table		
102/17/37	2 910 401 289	Hex Socket Head Cap Screw	M10x20-12.9 DIN 912-	
102/17/40	3 603 435 056	Set screw		
102/17/44	1 600 150 013	Spring Washer		
102/17/46	3 603 391 007	Thread-forming tap. Screw	UM5x10-ST DIN 7500-	
102/17/50	1 601 334 013	Chip Deflector		
125	3 600 109 026	Sealing disk		
149	2 603 490 024	Torx Oval-Head Screw	4x25	
652	2 607 225 937	Charger	CN GAL 1880 CV 220V/14,4-18V	
653	2 607 337 069	Battery Pack	BBS MR, 18V, 5,0 Ah 48 S	

Spare parts list

Item	Part Number	Description
802	3 607 031 879	DC motor
808	3 601 119 930	Nameplate
825	3 607 031 860	Eccentric Shaft

Illustration - Type - E

3 601 J26 200
 Issue | 18-12
 Stand | 19-02-26 **Fig./Abb. 1**

