



**BOSCH**

# Cordless Drill Driver

GSR 18V-350 | 3 601 JK3 210

---

## Table of Content

Spare parts list.....	2
Illustration - Type.....	3

# Cordless Drill Driver | GSR 18V-350 | 3 601 JK3 210

## Spare parts list

Item	Part Number	Description	Illustration
1	1 605 806 62H	Housing	1
3	1 619 P15 696	Stator	1
5	1 600 A01 Z04	Changeover Lever	1
6	2 607 202 513	Electronics Module	1
8	1 600 A02 937	Warning Label	1
9	1 601 11C 4KH	Manufacturer's nameplate	1
25	2 609 111 944	Keyless Chuck	1
32	1 600 A02 91C	Switchover Unit	1
42	1 601 11C 49H	Sticker	1
45	1 600 A02 659	Gear Box	1
46	1 609 280 477	Compression Spring	1
91	1 607 A35 0BM	Battery Pack     BAT612 18V 2.0Ah Li SCM	1
91	1 607 A35 0MB	Battery Pack	1
101	2 609 110 201	Torx Flat-Head Screw     3x16	1
107	2 603 421 229	Countersunk-Head Screw     M6x23 LEFTHAND THREADS	1
652	1 600 A02 7W3	Clip	1
653	2 607 226 287	Charger     US GAL 18V-20 120V / 2A	1
802	1 607 000 EC2	Rotor	1
808	1 601 11A 8Y2	Nameplate	1

Illustration - Type - E

