



BOSCH

Cordless Drill Driver

GSR 18 V-EC BT | 3 601 JE8 180

Table of Content

Spare parts list.....	2
Illustration - Type.....	3

Cordless Drill Driver | GSR 18 V-EC BT | 3 601 JE8 180**Spare parts list**

Item	Part Number	Description
1	2 609 101 487	Housing
2	1 619 P12 045	Stator 18V
4	1 607 233 5A9	Electronics Module 18V
4/3	1 607 503 060	Printed-Board Assembly
4/9	1 600 712 03J	Shrinkable Tube
5	2 609 101 484	Adjusting lever
9	2 609 136 522	Manufacturer's nameplate GSR 18 V-EC
25	2 609 111 944	Keyless Chuck
32	2 609 199 812	Switchover Unit
45	2 609 199 725	Gear Box
46	1 609 280 477	Compression Spring
47	2 609 101 490	Lens
91	1 607 A35 0M0	Battery Pack GBA 18V 4.0Ah
101	2 609 110 353	Torx Oval-Head Screw
103	2 609 110 835	Nut
107	2 603 421 229	Countersunk-Head Screw M6x23 LEFTHAND THREADS
116	2 609 101 542	Color clip
653	2 607 225 937	Charger CN GAL 1880 CV 220V/14,4-18V
654/1	2 609 111 584	Clip
654/2	2 609 110 834	Screw
660	2 609 199 748	Bit holder
661	1 600 A00 FC2	Color clip
803	2 609 199 894	DC motor 18V
804	1 609 280 820	Contact retainer 18V
808	1 601 11A 5MR	Nameplate

Illustration - Type - E

