




Model GTU01Z Parts List

Item#	Part#	Description	Q'ty
001	183X11-5	LEFT GRIP SET	1
	D10	INC. 3	
002	266326-2	TAPPING SCREW 4X18	4
003	183X11-5	LEFT GRIP SET	1
	D10	INC. 1	
004	922383-7	H.S.H.BOLT M6X60 WITH WR	1
005	257885-7	SLEEVE 6	1
006	122D95-8	COVER L ASSEMBLY	1
	D10	INC. 27,28	
007	422906-6	HANDLE GUARD	4
008	347A13-9	HANDLE	1
009	922342-1	HEX. SOCKET HEAD BOLT M6X25	8
010	266326-2	TAPPING SCREW 4X18	1
011	141S48-8	HANDLE COVER COMPLETE	1
	C10	818M17-5 CAUTION LABEL	1
012	413J46-1	LEAD HOLDER	1
013	266326-2	TAPPING SCREW 4X18	4
014	183X10-7	RIGHT GRIP SET	1
	D10	INC. 22	
015	458819-5	LOCK ON BUTTON COVER	1
016	413J58-4	SWITCH SUPPORT	1
017	650035-7	SWITCH C3JW-4BM-1L-R	1
018	458816-1	SWITCH COVER	1
019	231433-0	COMPRESSION SPRING 4	1
020	412551-5	LOCK OFF BUTTON	1
021	620E29-6	DIAL CIRCUIT	1
022	183X10-7	RIGHT GRIP SET	1
	D10	INC. 14	
023	266467-4	TAPPING SCREW 4X50	6
024	183X13-1	HOUSING SET	1
	C10	263005-3 RUBBER PIN 6	2
	C20	8032A7-2 XGT LOGO LABEL	1
025	620J16-5	CONTROLLER	1
027	232676-7	COMPRESSION SPRING 7	1
028	413J53-4	HOOK	1
029	8584F9-0	GTU01 SERIAL NO. LABEL	1
030	632P49-4	TERMINAL UNIT	1
031	911138-5	P.H.SCREW M4X20 WITH WR	4
032	413J44-5	MOTOR HOUSING	1
033	629B88-9	STATOR	1
035	265620-9	TAPPING SCREW FLANGE 4X18	2
036	211022-7	BALL BEARING 607ZZ	1
037	519789-4	ROTOR ASSEMBLY	1
	D10	INC. 36,38	
038	211087-9	BALL BEARING 6200DDW	1
040	911138-5	P.H.SCREW M4X20 WITH WR	4
041	136830-4	MOTOR BRACKET ASSY	1
	C10	213406-5 O RING 30	1
042	213A27-9	O-RING 115	1
044	8584F2-4	GTU01 NAME PLATE	1
045	961052-5	RETAINING RING (EXT) S-12	1

046	267104-3	FLAT WASHER 12	1
047	141K49-8	SPUR GEAR 42 COMPLETE	1
048	267104-3	FLAT WASHER 12	1
049	313437-5	SPEED CHANGE RING	1
050	327A22-4	SHAFT	1
051	267104-3	FLAT WASHER 12	1
052	141K50-3	SPUR GEAR 49 COMPLETE	1
053	267104-3	FLAT WASHER 12	1
054	254239-9	KEY 4	1
055	227984-9	HELICAL GEAR 13	1
056	961006-2	RETAINING RING S-10	1
057	211012-0	BALL BEARING 606ZZ	1
058	211016-2	BALL BEARING 626LLB	1
059	141N61-6	SPUR GEAR 10-16 COMPLETE	1
060	413J48-7	GEAR COVER	1
061	961056-7	RETAINING RING S-16	1
062	227985-7	HELICAL GEAR 34	1
063	254211-1	KEY 5	1
064	136891-4	GEAR CASE ASSEMBLY	1
	C10 213507-9	O RING 40	1
065	266459-3	TAPPING SCREW 5X25	4
067	211278-2	BALL BEARING 6203DDW	1
068	422905-8	FELT RING 24	1
069	327A23-2	SPINDLE	1
070	257884-9	RING 33	1
071	285821-3	BEARING RETAINER 22-41	1
072	763183-4	DRILL CHUCK S13	1
073	961017-7	STOP RING E-3	2
074	256A24-2	PIN 4	1
075	347A11-3	CHANGE PLATE A	1
076	234218-3	COMPRESSION SPRING 5	2
077	347A12-1	CHANGE PLATE B	1
080	161568-2	LOCK BUTTON COMPLETE	1
081	232344-2	COMPRESSION SPRING 3	1
082	213370-0	O RING 22	1
083	136822-3	CHANGE LEVER ASSEMBLY	1
	D10	INC. 80-82	
084	136821-5	CHANGE PLATE ASSEMBLY	1
	D10	INC. 73-77	
085	422975-7	KEY HOLDER	1
086	136892-2	GEAR ASSEMBLY	1
	D10	INC. 45-57	
A01	763259-7	CHUCK KEY S13	1