




Model GTW01 Parts List

Item#	Part#	Description	Q'ty
001	165074-9	CHIP ROD	1
002	233444-1	COMPRESSION SPRING 13	1
003	234143-8	COMPRESSION SPRING 25	1
004	257941-3	SPIRO LOCK WASHER 62	1
005	327C72-1	SPACER	1
006	257940-5	SPIRO LOCK WASHER 70	1
007	327C74-7	OUTER SUPPORT	1
008	266022-2	- SET SCREW(DOG POINT) M8X8	2
009	153872-3	INNER SUPPORT COMPLETE	1
010	211611-8	BALL BEARING 6810	1
011	267282-9	FLAT WASHER 60	1
012	212954-1	NEEDLE CAGE 810	8
013	227117-6	SPUR GEAR 20	4
014	310147-5	CARRIER	1
015	256228-0	PIN 8	4
016	216207-0	WASHER 2542	1
017	212954-1	NEEDLE CAGE 810	4
018	226270-5	SPUR GEAR 25	4
019	226275-5	SPUR GEAR 11	1
020	256227-2	PIN 8	4
021	216207-0	WASHER 2542	1
022	211044-7	BALL BEARING 694	4
023	226269-0	SPUR GEAR 25	4
024	226273-9	SPUR GEAR 14	1
025	256226-4	PIN 4	4
026	216403-0	THRUST NEEDLE GAUGE 1528	1
027	227118-4	INTERNAL GEAR 53-66	1
028	327C73-9	BRACKET	1
029	257929-3	SPIRO LOCK WASHER 52	1
030	257186-3	RING 44	1
031	211221-1	BALL BEARING 6902	1
032	141T01-0	GEAR CASE COMPLETE	1
	C10 263002-9	RUBBER PIN 4	2
033	922123-3	HEX. SOCKET HEAD BOLT M4X14	4
034	226812-5	GEAR 14-41	1
035	211098-4	BALL BEARING 699	1
036	233098-4	COMPRESSION SPRING 4	1
037	312E62-9	ROD SUPPORTER	1
038	344062-1	STOPPER PLATE	1
039	413T74-6	REAR COVER	1
040	911118-1	PAN HEAD SCREW M4X12	2
041	922123-3	HEX. SOCKET HEAD BOLT M4X14	4
042	210013-5	BALL BEARING 698VV	1
043	226651-3	HELICAL GEAR 30	1
044	212048-2	THRUST NEEDLE BEARING 617	1
045	226711-1	SPIRAL BEVEL GEAR 12	1
046	211097-6	BALL BEARING 6000LLB	1
047	226476-5	HELICAL GEAR 18	1
048	211031-6	BALL BEARING 608LLB	1
049	256225-6	PIN 4	1
050	141T00-2	GEAR HOUSING COMPLETE	1

051	347B90-7	HOOK	1
052	265491-4	H.S. BUTTON HEAD BOLT M5X16	2
053	211097-6	BALL BEARING 6000LLB	1
054	922148-7	HEX. SOCKET HEAD BOLT M4X25	4
055	344470-6	BEARING RETAINER	1
056	911111-5	PAN HEAD SCREW M4X10 WITH W	3
057	519831-1	ROTOR ASS'Y	1
	D10	INC. 58	
058	211021-9	BALL BEARING 607LB	1
059	265995-6	TAPPING SCREW 4X18	2
060	458306-4	BAFFLE PLATE	1
061	629C12-8	STATOR	1
062	620K96-7	CONTROLLER B	1
063	638A32-9	LEAD UNIT	1
064	652119-7	PAN HEAD SCREW M2X6	6
065	458302-2	MOTOR HOUSING	1
066	922909-5	HEX. SOCKET HEAD BOLT M4X35	4
067	8141X6-4	GTW01 NAME PLATE	1
068	265995-6	TAPPING SCREW 4X18	6
069	1830C9-9	HANDLE SET	1
	C10	263005-3 RUBBER PIN 6	2
	C20	422226-8 SPONGE SHEET	1
	C30	8068T1-2 INDICATION LABEL	1
	C40	816R78-9 CAUTION LABEL	1
	D10	INC. 77	
070	922149-5	H.S.H.BOLT M4X25 WITH WG	2
071-1	311928-0	CHIP LEVER	1
072	458303-0	SWITCH LEVER	1
073	650033-1	SWITCH C3XA-3PSPM-1	1
074	620M98-5	CONTROLLER	1
075	632P64-8	TERMINAL UNIT	1
076	8141Y6-1	GTW01 SERIAL NO.LABEL	1
077	1830C9-9	HANDLE SET	1
	C10	263005-3 RUBBER PIN 6	2
	C20	422226-8 SPONGE SHEET	1
	C30	8068T1-2 INDICATION LABEL	1
	C40	816R78-9 CAUTION LABEL	1
	D10	INC. 69	
078	620809-0	LED CIRCUIT	1
079	265995-6	TAPPING SCREW 4X18	2
A01	764361-9	OUTER SLEEVE 20-37	1
A02	764419-4	INNER SLEEVE 3/4-38 COMPLETE	1
A03	153909-6	OUTER SLEEVE 22-39 COMPLETE	1
A04	764418-6	INNER SLEEVE 22-39 COMPLETE	1
A05	783001-0	SCREWDRIVER 6	1
A06	161347-8	SHOULDER BELT	1
A07	821921-1	PLASTIC CARRYING CASE	1
	C10	162271-8 LATCH	2